



**Advanced Safety and User Experience**

# **Error Code Document**

## **RESIM - ERROR CODE DEFINITION**

### **Version 2.9**

April 12, 2021

Table of Contents

1

PURPOSE .....

3

1.1

Scope .....

3

1.2

References .....

3

1.3

Abbreviations and Acronyms .....

3

2

Resim exit codes .....

4

3

Resim console print messages .....

5

4

SIL Internal Error enum codes .....

9

5

Notes .....

12

6

Revision Record .....

13

**1 PURPOSE**

This document gives the Error code of RESIM Application.

**1.1 Scope**

RESIM Error code implementation is done based on requirements.

**1.2 References**

The following online resources provide the foundation for this document.

| Ref. | Title | Version |
|------|-------|---------|
| 1    |       |         |
| 2    |       |         |
| 3    |       |         |
| 4    |       |         |
| 5    |       |         |

**1.3 Abbreviations and Acronyms**

| Acronym | Description |
|---------|-------------|
|         |             |
|         |             |
|         |             |

## 2 Resim exit codes

Following are the exit codes that are returned at the exit of resim application.

| Sl. No | EXIT CODES                            | Condition for EXIT Code                                                                                                                      | Exit code number |
|--------|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| 1.     | RESIM_SIL_INIT_FAILED                 | SIL initialization failed                                                                                                                    | -3               |
| 2.     | RESIM_SIL_BINARY_FILE_LOAD_FAILED     | When dll loading is failed                                                                                                                   | -2               |
| 3.     | RESIM_EXIT_SUCCESS                    | When RESIM execution is successful                                                                                                           | 0                |
| 4.     | RESIM_EXIT_FAILURE                    | When RESIM execution is not successful                                                                                                       | 1                |
| 5.     | RESIM_INCORRECT_CMD_ARGUMENT          | When the number of arguments or the arguments are not given properly                                                                         | 2                |
| 6.     | RESIM_INVALID_CUSTOMER_IN_CONFIG_FILE | When customer name is not given correctly in the configuration file                                                                          | 3                |
| 7.     | RESIM_CSV_FILE_READ_ERROR             | Input CSV file read error.                                                                                                                   | 4                |
| 8.     | RESIM_LOG_LIST_READ_ERROR             | Log list/json read error has encountered.                                                                                                    | 5                |
| 9.     | RESIM_CONFIG_FILE_ERROR               | Configuration xml file read/parsing failed.                                                                                                  | 6                |
| 10.    | RESIM_JSON_FILE_ERROR                 | Json file parsing is failed.                                                                                                                 | 7                |
| 11.    | RESIM_CONTINUOUS_MODE_FILE_ERROR      | Files are not in continuous mode                                                                                                             | 8                |
| 12.    | RESIM_EXIT_WARNINGS                   | Resim exit with Warnings due to bad log/calibration data decoding failure/F360_GDSR failure/Scan Index jump/Bus spec ID missing in few logs. | 9                |

### 3 Resim console print messages

The relevant console prints that are printed from resim framework are listed below with comments.

| Sl. No | Console print messages                                                                                                                                 | Remarks/comments                                                                                                                            |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| 1.     | [WARNING]: Received duplicate F360 internal data chunk with wrong data at scan index: NNNNNN for running count: NNN                                    | Resim framework received duplicate of RECU F360 data chunk with wrong data at scan index NNNNNN at running count N.                         |
| 2.     | [WARNING]: Found F360 internal data chunk missing in the trace for running count: N                                                                    | In the trace there is F360 internal data chunk is missed at running count N.                                                                |
| 3.     | [WARNING]: UDP Frame is missing                                                                                                                        | Found UDP frame missing                                                                                                                     |
| 4.     | [ERROR]: Number of file paths provided in the json file are not equal.                                                                                 | Json file has the number of file path counts are not equal.                                                                                 |
| 5.     | [ERROR]: Required Bus Spec ID not found in SRR_DEBUG trace file: <filename>!!<br>Please provide trace file with Bus Spec ID 69632, 69633, 69634, 69635 | Mandatory bus spec IDs from the mf4 file listed under key SRR_DEBUG in json are not present.                                                |
| 6.     | [ERROR]: Required Bus Spec ID not found in BN_CALIFR Log: <filename>!!<br>Please provide log with CAN FD data with Spec ID 526, 548 or 549 and 550.    | Mandatory bus spec IDs from the mf4 file listed under key BN_CALIFR in json are not present.                                                |
| 7.     | [ERROR]: Required Bus Spec ID not found in BN_FASETH Log: <filename>!!<br>Please provide log with Spec ID (0xc600afd0) and (0xc610afd0).               | Mandatory bus spec IDs from the mf4 file listed under key BN_FASETH in json are not present.                                                |
| 8.     | [ERROR]: Error in Reading Log List...<br>Exiting Resimulation...                                                                                       | Error in reading the input file list/json file.                                                                                             |
| 9.     | [WARNING]: CRC error found in the stream Z at scan index NNNN for sensor X                                                                             | UDP packets of Z stream from sensor X has CRC mismatch at scan index NNNN.                                                                  |
| 10.    | [WARNING]: Checksum error found in the stream Z at scan index NNNN for sensor X                                                                        | Z stream from sensor X has checksum mismatch at scan index NNNN.                                                                            |
| 11.    | [WARNING]: Found UDP data packets missing in the stream Z at scan index NNNN for sensor X                                                              | UDP Z stream from sensor X has missing data packets at scan index NNNN.                                                                     |
| 12.    | [INFO]: Decoding Calibration data/F360 internals for Log <filename>                                                                                    | Resim framework is ready for decoding the calibration data and/ or F360/GDSR internals from the input UDP data recorded in the trace.       |
| 13.    | [INFO]: Decoding Calibration data for the log <filename>                                                                                               | Resim framework is ready for decoding the calibration data for Sensors from the input UDP data recorded in the trace.                       |
| 14.    | [INFO]: Started F360 internal data decoding                                                                                                            | Resim framework received RECU F360 data and started decoding F360 internals.                                                                |
| 15.    | [INFO]: Started F360 internal data decoding from next instance at scan index: NNNNNN                                                                   | Resim framework received the next instance of RECU F360 data at scan index NNNNNN and restarted decoding F360 internals from this instance. |

|     |                                                                                           |                                                                                                                                                              |
|-----|-------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 16. | [INFO]: EOF reached. F360 Internals decoding is incomplete                                | During the F360 decoding process, the EOF reached: not all the required number chunks of F360 are received from the trace hence F360 decoding is incomplete. |
| 17. | [WARNING]: Calibration decoding is successful but GDSR internals failed for : SRR_RL      | Calibration decoding is done successfully however the GDSR internal data decoding failed for this sensor.                                                    |
| 18. | [WARNING]: Calibration decoding failed but GDSR internals obtained for: SRR_RL            | Calibration decoding is failed however the GDSR internal data decoding is successful for this sensor.                                                        |
| 19. | [WARNING]: Calibration and GDSR internals decoding failed for: SRR_RL                     | Calibration decoding and GDSR internal data decoding is successful for this sensor.                                                                          |
| 20. | [WARNING]: Calibration decoding failed for: SRR_RL                                        | Calibration decoding is failed for this sensor.                                                                                                              |
| 21. | [WARNING]: Calibration decoding is successful but F360 internals failed for: RDR_ECU      | Calibration decoding is successful however the F360 internal data decoding is failed for RADAR ECU.                                                          |
| 22. | [WARNING]: Calibration decoding failed but F360 internals obtained for: RDR_ECU           | Calibration decoding is failed however the F360 internal data decoding is successful for RADAR ECU.                                                          |
| 23. | [WARNING]: Calibration and F360 internals decoding failed for: RDR_ECU                    | Calibration decoding and F360 internal data decoding failed for RADAR ECU.                                                                                   |
| 24. | [WARNING]: UDP data is not found for the RECU in the file.                                | The current file is in short of RECU UDP data.                                                                                                               |
| 25. | [WARNING]: UDP data is not found for the sensor SRR_RL in the file.                       | The current file is in short of sensor SRR_RL UDP data.                                                                                                      |
| 26. | [WARNING]: Directory: /home/resimResult... doesn't have Read permission                   | The specified directory has no read permission.                                                                                                              |
| 27. | [WARNING]: Resim cannot proceed due to read/write permission error                        | Found read/write permission error for the specified folder/file path. Hence resim is stopping.                                                               |
| 28. | [WARNING]: ECU SW stream ECU_CORE_0 has UDP packet loss in Scan Index: NNNN               | RADAR ECU core 0 stream has UDP packet loss at the specified scan index.                                                                                     |
| 29. | [WARNING]: ECU SW stream ECU_CORE_0 has checksum failed in Scan Index:                    | RADAR ECU core 0 stream has UDP packet has checksum data error at the specified scan index.                                                                  |
| 30. | [ERROR] : Unknown Program Tool Id is found in the log <FILENAME>                          | The md5 file has unknown program ID.                                                                                                                         |
| 31. | [WARNING]: Unable to open file <FILENAME>. Max file path length allowed is 260 characters | The file FILENAME could not be opened due to the longer file path name. Maximum allowed path length is 260 characters.                                       |
| 32. | [ERROR]: Resim failed to open the md5 file                                                | The provided MDF file open is failed.                                                                                                                        |
| 33. | [ERROR]: Resim found no data in md5 file                                                  | The provided MDF file has either no data or is corrupted.                                                                                                    |
| 34. | [INFO]: F360 decoding failed for sensor RDR_ECU                                           | F360 decoding is failed due to either packet loss/incomplete data/duplicate chunk ID with wrong data.                                                        |
| 35. | [INFO]: F360 internal data decoding is successful.                                        | Resim framework received all the required number of chunks for F360 data and F360 internal data decoding is successful.                                      |
| 36. | [INFO]: Calibration obtained for sensor X                                                 | Resim received and decoded calibration data from UDP trace from the sensor X successfully.                                                                   |

|     |                                                                                                                                   |                                                                                                                                                                                              |
|-----|-----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 37. | [INFO]: Calibration and F360 data decoding is successful for the log <filename>                                                   | All the required calibration data and F360 data for RECU are decoded successfully from the trace.                                                                                            |
| 38. | [INFO]: Calibration data decoding is successful for the log <filename>                                                            | All the required calibration data for Sensors are decoded successfully from the trace.                                                                                                       |
| 39. | [WARNING]: Calibration decoding failed for sensor SRR_RL                                                                          | The calibration data decoding from the trace is failed for the sensor SRR_RL                                                                                                                 |
| 40. | WARNING]: Calibration and GDSR decoding failed for sensor SRR_RL                                                                  | The calibration data decoding and GDSR internal decoding failed for the sensor SRR_RL in the trace.                                                                                          |
| 41. | [INFO]: Starting resimulation for the first log in the list...                                                                    | Resim framework starting the resimulation operation from the first log in the given list of traces.                                                                                          |
| 42. | [INFO]: Running Resim for Log <filename>                                                                                          | Resim framework currently running resim and processing the trace.                                                                                                                            |
| 43. | [INFO]: Running Sequential mode Resim for Log <filename>                                                                          | Resim framework currently running resim and processing the trace in sequential mode.                                                                                                         |
| 44. | [INFO]: Sequential mode resim is completed for the log <filename>                                                                 | Resimulation in sequential is completed mode for the trace <filename>                                                                                                                        |
| 45. | MODE:ALL Algorithms    Current Scan Index- NNNN<br>Radar- N                                                                       | SIL is running in CDC mode. Current scan index processed is NNNN by the sensor N                                                                                                             |
| 46. | MODE: TRACKER ONLY    Current Scan Index- NNNN<br>Radar- N                                                                        | SIL is running in tracker mode. Current scan index processed is NNNN by the sensor N                                                                                                         |
| 47. | Unsupported stream version : N for :XYZ stream                                                                                    | The UDP stream XYZ of version N has no support currently in this package of Resim.                                                                                                           |
| 48. | Unsupported stream size : NNN for : XYZ stream                                                                                    | The UDP stream XYZ has size mismatch.                                                                                                                                                        |
| 49. | unsupported Stream Number: N is provided in the given logs for : XYZ stream                                                       | The UDP stream XYZ has no support currently in this package of Resim.                                                                                                                        |
| 50. | [WARNING]: Resim encountered bad Log: <Filename>                                                                                  | The current processing file found to be a bad log.                                                                                                                                           |
| 51. | [WARNING]: BAD_LOG: RECU UDP data is missing in the file.<br>OR<br>[WARNING]: BAD_LOG: Sensor XX UDP data is missing in the file. | The Sensor/s and ECU UDP cycles a encountered synchronous radar cycles. This could be because one/more sensors have stopped logging the UDP data or one/more sensors UDP data are corrupted. |
| 52. | [WARNING]: BAD_LOG: UDP stream loss for two continuous cycles : Sensor ID = N (XX), Scan Index = NNNN                             | Bad log encountered with UDP stream loss in two consecutive radar cycles.                                                                                                                    |
| 53. | [WARNING]: BAD_LOG: Radar ECU is enabled but there is no ECU data in log file                                                     | Bad log, since the input log has no RECU UDP data to process.                                                                                                                                |
| 54. | [WARNING]: BAD_LOG: Mismatch in number of cycle count in the file                                                                 | Bad log encountered with mismatch in the total number of cycles count among the different sensors/RECU UDP data.                                                                             |

|     |                                                                                                                |                                                                                                                                                                                                                             |
|-----|----------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 55. | [WARNING]: MISMATCH_SCAN Sensor ID = N (XX),<br>Prev scan index = NNNN, Curr scan index = NNNN:<br>Delta = XYZ | Bad log encountered with the scan index jump in radar cycles or reset in the sensor.                                                                                                                                        |
| 56. | [WARNING]: Rejecting the Log: <Filename>                                                                       | The current log file is rejected by the resim due to unavailability of calibration or F360 data.                                                                                                                            |
| 57. | Resim application failed to decode F360 internal data for all the traces in the list.                          | Resim application could not decode RECU F360 data from all the trace files given in the list. This could be due to bad F360 data logging/ missing F360 UDP packets.                                                         |
| 58. | Resim application failed to decode calibration data for all the traces in the list.                            | Resim application could not decode Sensor calibration data from all the trace files given in the list. This could be due to bad calibration data logging/ missing calib UDP packets.                                        |
| 59. | Resim application failed to decode sensor calibration data for the traces in the list.                         | Resim application could not decode Sensor calibration data from some of the trace files given in the list. This could be due to bad calibration data logging/ missing calib UDP packets.                                    |
| 60. | Application has successfully recovered...                                                                      | Resim application recovered from processing bad log and resuming now with next log.                                                                                                                                         |
| 61. | Resimulation Operation Completed...                                                                            | Resim framework completed resimulation of all the files from the list successfully.                                                                                                                                         |
| 62. | Resimulation Operation Completed with warnings...                                                              | Resim framework completed resimulation of the files from the list, but encountered warnings such as UDP frame missing/continuous frame loss in two or more consecutive cycles/scan jump/mismatch in number of radar cycles. |
| 63. | Resimulation Operation Completed with errors...                                                                | Resim operation failed due to errors such as file open failed/calibration decoding failed for all the traces in the list/stream version mismatch/stream size mismatch.                                                      |
| 64. | [WARNING]: File doesn't have Read permission.<br>(filename)                                                    | This file name has no read permission.                                                                                                                                                                                      |

#### 4 SIL Internal Error enum codes

The following are SIL internal error codes.

| Sl. No | ERROR CODES that are internal to SIL                   | Condition for EXIT Code                                                              | Return code |
|--------|--------------------------------------------------------|--------------------------------------------------------------------------------------|-------------|
| 1.     | DPH_RR_ADAS_RESIM_NOK                                  | when xml config is not in correct format                                             | -1          |
| 2.     | DPH_RR_ADAS_RESIM_OK                                   | when initialization is fine                                                          | 0           |
| 3.     | DPH_RR_ADAS_RESIM_RUN_OK                               | when SIL is running fine                                                             | 1           |
| 4.     | DPH_RR_ADAS_RESIM_EOF                                  | End of function                                                                      | 2           |
| 5.     | DPH_RR_ADAS_SIL_NOT_FOUND                              | When SIL initialization fails                                                        | 3           |
| 6.     | DPH_RR_ADAS_RESIM_INIT                                 | When Resim Init is done                                                              | 4           |
| 7.     | DPH_RR_ADAS_RESIM_SIL_INIT_FAIL                        | When SIL execution fails                                                             | 5           |
| 8.     | DPH_RR_ADAS_MISSING_CAL                                | Calibration is missing                                                               | 6           |
| 9.     | DPH_RR_ADAS_MISSING_CAL_GDSR                           | GDSR data is missing from the UDP                                                    | 7           |
| 10.    | DPH_RR_ADAS_F360_DECODE_FAILED                         | when F360 decoding fails                                                             | 8           |
| 11.    | DPH_RR_ADAS_GDSR_DECODE_FAILED                         | When GDSR decoding fails                                                             | 9           |
| 12.    | DPH_RR_ADAS_ONLY_GDSR_DECODE_PASS                      | GDSR internal data Decoding only is done                                             | 10          |
| 13.    | DPH_RR_ADAS_CONFIG_ERROR                               | When there is an error in configuration                                              | 11          |
| 14.    | DPH_RR_ADAS_RESIM_CALIB_DONE                           | Calibration data Decoding is done                                                    | 12          |
| 15.    | DPH_RR_ADAS_RESIM_GDSR_DONE                            | GDSR internal data Decoding is done                                                  | 13          |
| 16.    | DPH_RR_ADAS_MISSING_FRAME                              | In case of UDP frame loss                                                            | 14          |
| 17.    | DPH_RR_ADAS_SENSOR_INVALID                             | Sensor position is not given                                                         | 15          |
| 18.    | DPH_RR_ADAS_UNSUPPORTED_STREAM_NUMBER_ERROR            | when there is unsupported stream number in logs                                      | 16          |
| 19.    | DPH_RR_ADAS_UNSUPPORTED_STREAM_VERSION_ERROR           | when there is stream version mismatch between FW and embedded                        | 17          |
| 20.    | DPH_RR_ADAS_UNSUPPORTED_EMBD_STREAM_VERSION_ERROR      | SIL engine Radar stream decoder is not updated to the Sensor embedded stream version | 18          |
| 21.    | DPH_RR_ADAS_UNSUPPORTED_RECU_EMBD_STREAM_VERSION_ERROR | SIL engine Radar stream decoder is not updated to the RECU embedded stream version   | 19          |
| 22.    | DPH_RR_ADAS_UNSUPPORTED_STREAM_SIZE_ERROR              | when there is stream size mismatch between FW and embedded                           | 20          |
| 23.    | DPH_RR_ADAS_CONSISTANCY_ERROR                          | UDP Frame consistency Error                                                          | 21          |
| 24.    | DPH_RR_ADAS_PLP_FILE_NEGATIVE_TIMESTAMP                | When PLP timestamp is negative                                                       | 22          |
| 25.    | DPH_RR_ADAS_PLP_FILE_EMPTY_PATH                        | When PLP file path is empty                                                          | 23          |
| 26.    | DPH_RR_ADAS_PLP_FILE_OPEN_ERROR                        | When there is an error in opening the file                                           | 24          |
| 27.    | DPH_RR_ADAS_FILE_TIMESTAMP_ARRAY_ERR                   | Error in timestamp                                                                   | 25          |
| 28.    | DPH_RR_ADAS_PLP_FILE_TRANSITION_ERR                    | PLP file transition error                                                            | 26          |
| 29.    | DPH_RR_ADAS_PLP_TIMESTAMP_MISMATCH_ERR                 | PLP timestamp mismatch found                                                         | 27          |
| 30.    | DPH_RR_ADAS_UDP_PAYLOAD_EMPTY                          | When UDP payload is empty                                                            | 28          |
| 31.    | DPH_RR_ADAS_CAN_PAYLOAD_EMPTY                          | When CAN payload is empty                                                            | 29          |
| 32.    | DPH_RR_ADAS_SOMEIP_OBJLIST_EMPTY                       | When SOMEIP object list is empty                                                     | 30          |
| 33.    | DPH_RR_ADAS_SOMEIP_PAYLOAD_EMPTY                       | When SOMEIP payload is empty                                                         | 31          |

|     |                                       |                                               |    |
|-----|---------------------------------------|-----------------------------------------------|----|
| 34. | DPH_RR_ADAS_STREAM_UNSUPPORTED        | When stream is unsupported                    | 32 |
| 35. | DPH_RR_ADAS_CDC_DATA_MISSING          | When CDC data is missing                      | 33 |
| 36. | DPH_RR_ADAS_CDC_VERSION_ERR           | When there is an error in cdc version         | 34 |
| 37. | DPH_RR_ADAS_CDC_INVALID_POINTER       | When cdc pointer is invalid                   | 35 |
| 38. | DPH_RR_ADAS_Z7A_VERSION_ERR           | When there is an error in z7a version         | 36 |
| 39. | DPH_RR_ADAS_Z7A_SIZE_ERR              | When there is an error in z7a size            | 37 |
| 40. | DPH_RR_ADAS_Z7A_CHKSM_ERR             | When there is checksum failure for z7a stream | 38 |
| 41. | DPH_RR_ADAS_Z7A_INVALID_POINTER       | When z7a pointer is invalid                   | 39 |
| 42. | DPH_RR_ADAS_Z7B_VERSION_ERR           | When there is an error in z7b version         | 40 |
| 43. | DPH_RR_ADAS_Z7B_SIZE_ERR              | When there is an error in z7b size            | 41 |
| 44. | DPH_RR_ADAS_Z7B_CHKSM_ERR             | When there is an error in z7b checksum        | 42 |
| 45. | DPH_RR_ADAS_Z7B_INVALID_POINTER       | When z7b pointer is invalid                   | 43 |
| 46. | DPH_RR_ADAS_Z4_VERSION_ERR            | When there is an error in z4 version          | 44 |
| 47. | DPH_RR_ADAS_Z4_SIZE_ERR               | When there is an error in z4 size             | 45 |
| 48. | DPH_RR_ADAS_Z4_CHKSM_ERR              | When there is an error in z4 checksum         | 46 |
| 49. | DPH_RR_ADAS_Z4_INVALID_POINTER        | When z4 stream pointer is invalid             | 47 |
| 50. | DPH_RR_ADAS_Z7B_CUST_VERSION_ERR      | When there is z7b custom version error        | 48 |
| 51. | DPH_RR_ADAS_Z7B_CUST_SIZE_ERR         | When z7b custom stream size is invalid        | 49 |
| 52. | DPH_RR_ADAS_Z7B_CUST_CHKSM_ERR        | When z7b custom stream checksum is invalid    | 50 |
| 53. | DPH_RR_ADAS_Z7B_CUST_INVALID_POINTER  | When z4 custom stream pointer is invalid      | 51 |
| 54. | DPH_RR_ADAS_Z4_CUST_VERSION_ERR       | When z4 custom version is wrong               | 52 |
| 55. | DPH_RR_ADAS_Z4_CUST_SIZE_ERR          | When z4 custom size is wrong                  | 53 |
| 56. | DPH_RR_ADAS_Z4_CUST_CHKSM_ERR         | When z4 custom checksum is invalid            | 54 |
| 57. | DPH_RR_ADAS_Z4_CUST_INVALID_POINTER   | When z4 custom pointer is invalid             | 55 |
| 58. | DPH_RR_ADAS_CALIB_VERSION_ERR         | When calibration stream version is wrong      | 56 |
| 59. | DPH_RR_ADAS_CALIB_INVALID_POINTER     | When calibration pointer is invalid           | 57 |
| 60. | DPH_RR_ADAS_CALIB_DATA_ERR            | When calibration data is wrong                | 58 |
| 61. | DPH_RR_ADAS_ECU_CORE0_VERSION_ERR     | When ECU core0 version is wrong               | 59 |
| 62. | DPH_RR_ADAS_ECU_CORE0_SIZE_ERR        | When ECU core0 size is wrong                  | 60 |
| 63. | DPH_RR_ADAS_ECU_CORE0_CHKSM_ERR       | When ECU core0 checksum is wrong              | 61 |
| 64. | DPH_RR_ADAS_ECU_CORE0_INVALID_POINTER | When ECU core0 pointer is invalid             | 62 |
| 65. | DPH_RR_ADAS_ECU_CORE1_VERSION_ERR     | When ECU core1 version is wrong               | 63 |
| 66. | DPH_RR_ADAS_ECU_CORE1_SIZE_ERR        | When ECU core1 size is wrong                  | 64 |
| 67. | DPH_RR_ADAS_ECU_CORE1_CHKSM_ERR       | When ECU core1 checksum is wrong              | 65 |
| 68. | DPH_RR_ADAS_ECU_CORE1_INVALID_POINTER | When ECU core1 pointer is invalid             | 66 |
| 69. | DPH_RR_ADAS_ECU_VERSION_ERR           | When ECU core3 version is wrong               | 67 |
| 70. | DPH_RR_ADAS_ECU_SIZE_ERR              | When ECU core3 size is wrong                  | 68 |
| 71. | DPH_RR_ADAS_ECU_CHKSM_ERR             | When ECU checksum is wrong                    | 69 |
| 72. | DPH_RR_ADAS_ECU_CORE3_INVALID_POINTER | When ECU core3 pointer is invalid             | 70 |
| 73. | DPH_RR_ADAS_ECU_F360_SYNC_IN_PROGRESS | When F360 sync is in progress                 | 71 |
| 74. | DPH_RR_ADAS_ECU_F360_SYNC_ERR         | When there is F360 sync error                 | 72 |
| 75. | DPH_RR_ADAS_ECU_F360_GENERAL_ERR      | When there is F360 error                      | 73 |
| 76. | DPH_RR_ADAS_ECU_F360_INVALID_POINTER  | When F360 pointer is invalid                  | 74 |

|      |                                            |                                                                             |    |
|------|--------------------------------------------|-----------------------------------------------------------------------------|----|
| 77.  | DPH_RR_ADAS_ECU_OG_GENERAL_ERR             | Not applicable                                                              | 75 |
| 78.  | DPH_RR_ADAS_ECU_OG_INVALID_POINTER         | When ECU pointer is invalid                                                 | 76 |
| 79.  | DPH_RR_ADAS_GDSR_SYNC_IN_PROGRESS          | When GDSR sync is in progress                                               | 77 |
| 80.  | DPH_RR_ADAS_GDSR_SYNC_ERR                  | When there is GDSR sync error                                               | 78 |
| 81.  | DPH_RR_ADAS_GDSR_GENERAL_ERR               | Not applicable                                                              | 79 |
| 82.  | DPH_RR_ADAS_GDSR_INVALID_POINTER           | When GDSR pointer is invalid                                                | 80 |
| 83.  | DPH_RR_ADAS_GDSR_INVALID_CUSTOMER          | Not applicable                                                              | 81 |
| 84.  | DPH_RR_ADAS_SYM_VERSION_ERR                | When there is symbol version error                                          | 82 |
| 85.  | DPH_RR_ADAS_SYM_INVALID_POINTER            | When symbol pointer is invalid                                              | 83 |
| 86.  | DPH_RR_ADAS_SYM_SIZE_ERR                   | Symbol size error                                                           | 84 |
| 87.  | DPH_RR_ADAS_SYM_INVALID_CUSTOMER           | Not applicable                                                              | 85 |
| 88.  | DPH_RR_ADAS_MDF_TIMESTAMP_NEGATIVE         | When MDF timestamp is negative                                              | 86 |
| 89.  | DPH_RR_ADAS_MDF_TIMESTAMP_START_TIME_ERROR | When timestamp start time is wrong                                          | 87 |
| 90.  | DPH_RR_ADAS_MDF_TIMESTAMP_IN_SYNC          | When MDF timestamp is in sync                                               | 88 |
| 91.  | DPH_RR_ADAS_MDF_TIMESTAMP_OUT_OF_SYNC      | When MDF timestamp is out of sync                                           | 89 |
| 92.  | DPH_RR_ADAS_APP_QUEUE_FULL                 | SIL found one or more sensor's UDP data packets in the log went out of sync | 90 |
| 93.  | DPH_RR_ADAS_APP_BAD_LOG                    | The input trace has UDP data missing in two or more consecutive cycles.     | 91 |
| 94.  | DPH_RR_ADAS_MDF_UNKNOWN_PROG_ID            | The program ID in the mf4 file is unknown to the reader                     | 92 |
| 95.  | DPH_RR_ADAS_UDP_CONFIG_CUSTID_CONFLICT     | Found conflicting customer ID in UDP & Config file.                         | 93 |
| 96.  | DPH_RR_ADAS_UDP_FRAME_ERROR                | UDP data/ frame error found in the log.                                     | 94 |
| 97.  | DPH_RR_ADAS_MDF_NO_DATA_AVAILABLE          | MDF file has no UDP data                                                    | 95 |
| 98.  | DPH_RR_ADAS_MDF_FILE_OPEN_ERROR            | MDF file open failed                                                        | 96 |
| 99.  | DPH_RR_ADAS_READ_WRITE_ACCESS_ERROR        | The file path has read/write access error                                   | 97 |
| 100. | DPH_RR_ADAS_LENGTH_ERROR                   | The file path length is above the tolerance.                                | 98 |

**5    Notes**

None.

## 6 Revision Record

| Revision | Status   | Description / Reason for Revision                                                                                                                           | Date             | Author(s)     |
|----------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|---------------|
| 00       | Draft    | Initial Draft                                                                                                                                               | 27 December 2019 | Girija B      |
| 1.0      | Approved | Update on Error Code Definition                                                                                                                             | 27 December 2019 | Anju Satheesh |
| 2.0      | Approved | Updated resim console print messages                                                                                                                        | 19 June 2020     | Mrinal Das    |
| 2.1      | Approved | Updated additional resim console print messages                                                                                                             | 22 June 2020     | Kiran K R     |
| 2.2      | Approved | Updated additional resim console print messages                                                                                                             | 28 June 2020     | Kiran K R     |
| 2.3      | Approved | Updated additional resim console print messages                                                                                                             | 30 June 2020     | Kiran K R     |
| 2.4      | Approved | Updated additional resim console print messages                                                                                                             | 10 July 2020     | Kiran K R     |
| 2.5      | Approved | Updated resim print messages on section 2 with serial numbers 1, 2, 3, 9, 10, 11, 31, 32, 33 and 34.                                                        | 15 October 2020  | Kiran K R     |
| 2.6      | Approved | Updated resim print messages on section 2 with serial numbers 32 and 35. Newer print messages are added in section 2 with serial numbers 31, 33, 34 and 37. | 27 October 2020  | Kiran K R     |
| 2.7      | Approved | Newer print messages are added in section 2 with serial numbers 16 till 30.                                                                                 | 08 December 2020 | Kiran K R     |
| 2.8      | Approved | Additional console print is added in section 3 with serial number 63 and corrected the text Calib as Calibration.                                           | 04 January 2021  | Kiran K R     |
| 2.9      | Approved | Updated resim exit codes 8 and 9.                                                                                                                           | 12 April 2021    | Kiran K R     |
|          |          |                                                                                                                                                             |                  |               |