



1 Assembling your Dyson



dyson
USER GUIDE




IMPORTANT SAFETY INSTRUCTIONS
Please read carefully before use

2 Operating your Dyson




www.dyson.com

3 Washing your pre-motor filter



www.dyson.com

4 Emptying your clear bin™



6

Empty into a plastic bag (recommended for asthma/allergy sufferers)...



...or directly into a dustbin.

7 Optional

You may rinse the clear bin™ with water.

Do not use detergents.

Do not immerse the whole cleaner in water.


Do not remove bin inner or cone seals.

Ensure completely dry before replacing.


8

9

10



5 Changing/fitting belt



7

Optional

Turn belt through 90°, stretch and release over spindle.

8

Belt should be free of twists as shown.

9

9

10

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175