

DRAFT / NOT FOR ORDER / NO POWER / NO FIRE / production_release=false
K1 GLOW | RELAY + PCB SOCKET
K2 CLUTCH RUN | RELAY + PCB SOCKET
K3 CLUTCH ENABLE | RELAY + PCB SOCKET
J28 CLUTCH OUT | PIN1 SWITCHED+ | PIN2 GND
J27 GLOW OUT | PIN1 SWITCHED+ | PIN2 GND
HC160 CTRL
4 G
3 PA
2 A2
1 A1