SAMPLING

1 Sample rate (1-4, def 3)
4 = ~15.5 kHz, ~2.1 s
3 = ~10.3 kHz, ~3.2 s
2 = ~6.3 kHz, ~5.2 s
1 = ~3.4 kHz, ~9.6 s

2 Input source (0-1, def 1)
0 = mic, 1 = line

3 Input filter freq (0-99, def 99)
0 = closed ... 99 = calibrated max

4 Trigger mode (0-1, def 0)
0 = manual, 1 = auto (threshold)

5 Auto-trigger threshold (0-99, def 20)
Trigger level for mode 1

TUNING

6 Sample tune (0-99, def 50)
Global fine tune; 50 = center

7 Base note (0-99, def 60)
Recorded pitch; 60 = middle C

8 Coarse tune (0-48, def 24)
Semitones; 24 = zero (±24)

9 Fine tune (0-98, def 49)
~19 cents/step; 49 = zero

10 Detune mix (0-99, def 0)
Detune blend; 0 = dry

11 Detune amount (0-20, def 11)
10 = unison; curved to ±1 octave

12 Detune drift depth (0-4, def 0)
Slow random wander; 0 = off

PLAYBACK + LOOPING

13 Loop mode (0-1, def 1)
0 = one-shot, 1 = loop

14 Playback direction (0-1, def 0)
0 = forward, 1 = reverse

15 Sample start (0-99, def 0)

16 Sample end (0-99, def 99)

17 Loop start (0-99, def 0)
Plays within 15-16

18 Loop end (0-99, def 99)
Plays within 17-16

FILTER

21 Cutoff (0-99, def 99)

22 Resonance (0-99, def 20)

23 Keyboard tracking (0-98, def 49)
Bipolar; 49 = off

24 Velocity -> filter (0-99, def 0)

25 Velocity -> resonance (0-99, def 0)

AMP ENVELOPE

31 Amp attack (0-99, def 0)

32 Amp decay (0-99, def 40)

33 Amp sustain (0-99, def 50)

34 Amp release (0-99, def 30)

35 Velocity -> amp (0-99, def 99)
0 = constant; 99 = full velocity

FILTER ENVELOPE

41 Filter attack (0-99, def 0)

42 Filter decay (0-99, def 40)

43 Filter sustain (0-99, def 50)

44 Filter release (0-99, def 20)

45 Filter env -> cutoff (0-98, def 49)
Bipolar: 49 = zero

46 Filter env -> res (0-98, def 49)
Bipolar: 49 = zero

PITCH ENVELOPE

51 Pitch env attack (0-99, def 0)

52 Pitch env decay (0-99, def 20)

53 Pitch env sustain (0-99, def 0)

54 Pitch env release (0-99, def 10)

55 Pitch env depth (0-99, def 0)

56 Pitch env direction (0-1, def 1)
0 = down, 1 = up

LFO

61 LFO waveform (0-4, def 0)
0 tri · 1 saw up · 2 saw down · 3 square · 4 random S&H

62 LFO speed (0-99, def 4)
Curved; span set by param 76

63 LFO trigger (0-1, def 0)
0 = retrigger; 1 = free-run

64 LFO -> amp (0-99, def 0)

65 LFO -> cutoff (0-99, def 0)

66 LFO -> pitch (0-99, def 0)

67 LFO -> res (0-99, def 0)

76 LFO range (0-1, def 0)
0 = low, 1 = high

CONTROL / MIDI

71 MIDI channel (1-16, def 1)
Transmit and receive

72 Mod wheel function (0-4, def 0)
0 = edit param
1 = LFO speed
2 = LFO pitch
3 = LFO filter
4 = LFO amp

73 Mod wheel damping (0-3, def 1)
Pot smoothing; higher = smoother

74 Pitch bend range (1-12, def 2)
Semitones +/-

75 Pitch wheel disable (0-1, def 0)
0 = enabled, 1 = disabled
(MIDI bend still received)

77 MIDI mod wheel receive (0-1, def 0)
0 = on, 1 = off
(local wheel only; notes/bend still received)

UTILITY

Save Program: Seq Save -> slot 0-9 -> Enter (Cancel aborts)
Load Program: Seq Load -> slot 0-9 -> Enter; empty slot restores the default saw

Reset Params: Load Upper + Lower together; resets all except 71-75 and 77

Octave Up: Sample Upper
Octave Down: Sample Lower
Octave Reset: Sample Upper + Sample Lower simultaneously

Panic: Press Play Seq twice; cuts off all sounding notes