


MAESTRI

AIR OPERATED SELF-PRIMING DOUBLE DIAPHRAGM PUMPS

for DIESEL FUEL, OILS and WASTE OILS

Mod. AIR20/N - AIR20 - AIR20/C - AIR20/C/F



| Pos. | Q.ty | Mod. | Material | Description |
|------|------|------------|----------|---------------------|
| I | I | AIR20/R1 | PP | Central block |
| Ia | 2 | AIR20/R1A | PP | Warhead |
| 2 | I | AIR20/R2 | POM-C | Pneumatic exchanger |
| 3 | I | AIR20/R3 | AISI | Shaft |
| 3a | I | AIR20/R3A | NBR | O-ring shaft |
| 5 | 2 | AIR20/R5 | STEEL | Belleville Washer |
| 6 | 2 | AIR20/R6 | ALUMINUM | Air side cap |
| 7a | 2 | AIR20/R7A | Hytrel | Air diaphragm |
| 7b | 2 | AIR20/R7B | PTFE | Fluid diaphragm |
| 8 | 2 | AIR20/R8 | PP+VTR | Fluid side cap |
| 10 | 2 | AIR20/R10 | FELT | Silencer |
| 11 | 2 | AIR20/R11 | POM+VTR | Pump casing |
| 12a | I | AIR20/R12A | POM+VTR | Upper manifold |
| 12b | I | AIR20/R12B | POM+VTR | Lower manifold |

| Pos. | Q.ty | Mod. | Material | Description |
|------|------|------------|----------|----------------------|
| 13 | 4 | AIR20/R13 | ECTFE | Ball cage wile |
| 14 | 4 | AIR20/R14 | PTFE | Ball |
| 15a | 4 | AIR20/R15A | POM-C | Ball seat |
| 19 | 8 | AIR20/R19 | AISI | Screw manifold |
| 19a | 4 | AIR20/R19A | AISI | Washers manifold |
| 19b | 8 | AIR20/R19B | AISI | Nuts collector |
| 21 | 4 | AIR20/R21 | AISI | Screw pump casing |
| 21a | 4 | AIR20/R21A | AISI | Washers pump casing |
| 21b | 4 | AIR20/R21B | AISI | Nuts pump casing |
| 32 | 4 | AIR20/R32 | PTFE | Gasket upper |
| 33 | 4 | AIR20/R33 | PTFE | Gasket lower |
| 41 | 4 | AIR20/R41 | PTFE | Internal gasket seat |
| 47 | 2 | AIR20/R47 | PP | Spacer |
| 51 | I | AIR20/R51 | BRASS | Air connection |
| | I | AIR20/RKIT | | Spare kit AIR20 |