
Voltage Sensor



Inputs

- GND This is where you connect the low side of the voltage you are measuring. Caution!: This is the same electrical point as your Arduino ground.
- . VCC: The is where you connect the high side of the voltage you are measuring

Outputs

- S: This connects to your Arduino analog input.
- - (or minus): This connects to your Arduino ground.
- +: This is not connected. It does absolutely nothing... zilch... nada... jack diddly doo doo.

