

Division 03 Cast-in-Place Concrete

Practice file: Cedarline Training Hall, job SYNTH-HALL-01.

Original text. Not a real project and not a platform export.

Section 03 30 00.

Curing: keep cast-in-place concrete wet for 7 days when the daily low stays above 40 F.

Weather limit: do not place concrete when the air temperature is below 40 F or above 95 F.

Strength: do not load the slab until test cylinders reach 75 percent of the specified strength.

Project: Cedarline Training Hall, a one-story practice hall. This section covers the slab and the grade beams only.

Mix: the practice mix is called CH-4000. Design strength is 4000 psi at 28 days. Water added on site is not allowed.

Joints: saw cut control joints the morning after placement, at the spacing on sheet S-101.

Finish: light broom finish on walking surfaces. Do not add a shake-on hardener.

Cylinders: cast one set of three cylinders for every 50 cubic yards, and one set on the last truck of the day.

Hot weather: shade the forms and start curing the same day. The temperature cap above is the placement rule.

Cold weather: if the forecast low is under the temperature floor above, wait. Do not use a different number.

Repair: honeycombing deeper than 1 inch is written up as an issue. It is not patched in secret.

Related file: the vapor-barrier product sheet is Division 07. The open question about placement is RFI-014.