

Division 31 Earthwork

Practice file: Cedarline Training Hall, job SYNTH-HALL-01.

Original text. Not a real project and not a platform export.

Section 31 20 00. Excavation and fill under the practice hall pad.

Strip topsoil and stockpile it on the west of the pad, inside the fence.

Excavate to the elevations on sheet C-101. Those elevations are practice numbers for this file, not a survey.

Compact structural fill to 95 percent of the laboratory maximum density, tested every 500 square feet per lift.

Lift thickness: 8 inches loose, 6 inches after compaction.

Proof roll the subgrade with a loaded truck before the vapor barrier sheet goes down. Soft spots are removed and replaced.

Submittal SB-02 is the compaction report. Its status on the log is approved.

Utilities: the practice water line enters at grid A. Hand dig within 2 feet of that line.