

Sheet 1

File: ALU-V3.1-sheet1.kicad_sch

Sheet 2

File: ALU-V3.1-sheet2.kicad_sch

Sheet 3

File: ALU-V3.1-sheet3.kicad_sch

Sheet 4

File: ALU-V3.1-sheet4.kicad_sch

Sheet 5

File: ALU-V3.1-sheet5.kicad_sch

Sheet 6

File: ALU-V3.1-sheet6.kicad_sch

Sheet 7

File: ALU-V3.1-sheet7.kicad_sch

Sheet 8

Converted from Eagle schematic; see README.md

Sheet: /
File: ALU-V3.1.kicad_sch


Title: ALU-V3.1


Size: A4	Date:
----------	-------



KiCad E.D.A. 10.0.6

Rev:


Id: 1/10







Size: User	Date:	Rev:
KiCad E.D.A. 10.0.6		Id: 5/10



Converted from Eagle: ALU V3.1.sch sheet 5


Sheet: /Sheet 5/
File: ALU-V3.1-sheet5.kicad_sch


Title: ALU-V3.1 sheet 5

Size: User
KiCad E.D.A. 10.0.6

Date:

Rev:
Id: 6/10





Converted from Eagle: ALU V3.1.sch sheet 7

Sheet: /Sheet 7/
File: ALU-V3.1-sheet7.kicad_sch

Title: ALU-V3.1 sheet 7

Size: User	Date:	Rev:
KiCad E.D.A. 10.0.6		Id: 8/10

