P8X Instruction Set -- Quick Reference (rev D)

Opcodes, mnemonics and cycle counts generated live from genucode.py (the microcode source of truth) -- cannot drift from the hardware.

Operands: #imm immediate | addr 16-bit absolute | (Pn) ptr indirect | (Pn)+ post-increment | (no operand) implied. **By**=bytes, **Cy**=cycles (incl. fetch). **Flags (Fl):** C carry (active-high: ADD carry-out / SUB,CMP no-borrow A>=B), Z zero, N negative (bit7), V overflow. '-' = none. Signed branches test N^V / Z. **Memory (rev E):** $0000-1FFF ROM | $2000-FEFF RAM | $FF00-FFFF I/O. P0=PC, P3=stack (empty-descending). JZ/JNZ/JC are aliases of BZ/BNZ/BCP.

Op	Mnemonic	By	Cy	Fl	Description
System					
$00	NOP	1	2	-	No operation.
$01	HLT	1	2	-	Halt clock; resume only by reset.
$72	CLC	1	2	C	C:=0.
$73	SEC	1	2	C	C:=1.
Interrupts (rev C)					
$02	EI	1	2	-	Enable maskable interrupts (IE:=1).
$03	DI	1	2	-	Disable maskable interrupts (IE:=0).
$04	RTI	1	10	-	Return from interrupt: pop flags then PC; re-enable IE.
$08	IRQ	1	10	-	SW interrupt: push PC+flags, vector to $0808.
Load / store					
$10	LDA #imm	2	2	ZN	A:=immediate.
$11	LDB #imm	2	2	ZN	B:=immediate.
$12	LDA addr	3	6	ZN	A:=byte at addr (absolute).
$13	LDB addr	3	6	ZN	B:=byte at addr (absolute).
$14	STA addr	3	6	-	byte at addr:=A (absolute).
$15	LDA (P1)+	1	2	ZN	A:=[P1], P1++.
$16	LDA (P2)+	1	2	ZN	A:=[P2], P2++.
$17	LDA (P3)+	1	2	ZN	A:=[P3], P3++.
$19	STA (P1)+	1	2	-	[P1]:=A, P1++.
$1A	STA (P2)+	1	2	-	[P2]:=A, P2++.
$1B	STA (P3)+	1	2	-	[P3]:=A, P3++.
$1D	STA (P1)	1	2	-	[P1]:=A.
$1E	STA (P2)	1	2	-	[P2]:=A.
$1F	STA (P3)	1	2	-	[P3]:=A.
$51	LDA (P1)	1	2	ZN	A:=[P1] (P1 kept).
$52	LDA (P2)	1	2	ZN	A:=[P2] (P2 kept).
$53	LDA (P3)	1	2	ZN	A:=[P3] (P3 kept).
$88	LDA (P1+d)	2	7	CZN	A:=byte at P1+d (d unsigned 0..255). C from the address add, Z/N from A.
$89	LDA (P2+d)	2	7	CZN	A:=byte at P2+d.
$8A	LDA (P3+d)	2	7	CZN	A:=byte at P3+d (a stack local).
$8C	STA (P1+d)	2	9	CZN	byte at P1+d:=A. A kept; flags clobbered by the address add.
$8D	STA (P2+d)	2	9	CZN	byte at P2+d:=A.
$8E	STA (P3+d)	2	9	CZN	byte at P3+d:=A (a stack local).
ALU (A,B -> A)					
$20	ADD	1	2	CZN	A:=A+B.
$21	SUB	1	2	CZN	A:=A-B.
$22	AND	1	2	CZN	A:=A AND B.
$23	OR	1	2	CZN	A:=A OR B.
$24	XOR	1	2	CZN	A:=A XOR B.
$25	CMP	1	2	CZN	Flags from A-B; A unchanged.
$26	INC	1	2	CZN	A:=A+1 (B unused).
$27	DEC	1	2	CZN	A:=A-1 (B unused).
$28	SHL	1	2	CZN	A:=A<<1, 0->bit0, out->C.
$29	SHR	1	2	CZN	A:=A>>1, 0->bit7, out->C.
$2A	ROL	1	2	CZN	Rotate A left through carry.
$2B	ROR	1	2	CZN	Rotate A right through carry.
ALU with T (rev C; 2nd operand=T, B preserved)					
$80	ADDT	1	2	CZN	A:=A+T (B preserved).
$81	SUBT	1	2	CZN	A:=A-T (B preserved).
$82	ANDT	1	2	CZN	A:=A AND T (B preserved).
$83	ORT	1	2	CZN	A:=A OR T (B preserved).
$84	XORT	1	2	CZN	A:=A XOR T (B preserved).
$85	CMPT	1	2	CZN	Flags from A-T; A,B unchanged.
$86	LDT #imm	2	2	-	T:=immediate.
$87	LDT addr	3	6	-	T:=byte at addr (absolute).

Op	Mnemonic	By	Cy	Fl	Description
Stack					
$70	PHA	1	2	-	Push A onto P3 stack.
$71	PLA	1	3	ZN	Pop A from P3 stack.
16-bit memory (rev D)					
$74	PHW addr	3	10	-	Push 16-bit word at addr (hi then lo: lies little-endian at P3+1).
$75	PLW addr	3	12	-	Pop 16-bit word into addr (lo then hi).
$76	LPW1 addr	3	9	-	P1 := 16-bit word at addr.
$77	LPW2 addr	3	9	-	P2 := 16-bit word at addr.
$78	MOVW dst,src	5	13	-	16-bit mem->mem: word at src -> dst.
$79	LPW3 addr	3	9	-	P3 := 16-bit word at addr (restore a saved SP).
$BD	PHW (P1+d)	2	11	CZN	Push the word at P1+d (hi then lo). A!; flags from the address add.
$BE	PHW (P2+d)	2	11	CZN	Push the word at P2+d. A!
$BF	PHW (P3+d)	2	11	CZN	Push the word at P3+d, d measured before the push (a local/arg onto the stack). A!
Tier A: C-compiler ISA (2026-09, pure microcode; A! = clobbers A)					
$38	LDP1 #imm16	3	5	-	P1:=imm16 (3 bytes; was the LPL1/LPH1 pair).
$39	LDP2 #imm16	3	5	-	P2:=imm16.
$3A	LDP3 #imm16	3	5	-	P3:=imm16.
$3C	ADDP3 #imm	2	6	CZN	P3:=P3+imm8 (free a frame). A!; flags from the low byte.
$3D	SUBP3 #imm	2	6	CZN	P3:=P3-imm8 (allocate a frame). A!; flags from the low byte.
$90	LDW addr,(P1+d)	4	14	CZN	word at addr:=word at P1+d. A!
$91	LDW addr,(P2+d)	4	14	CZN	word at addr:=word at P2+d. A!
$92	LDW addr,(P3+d)	4	14	CZN	word at addr:=word at P3+d (local -> memory word). A!
$94	STW (P1+d),addr	4	14	CZN	word at P1+d:=word at addr. A!
$95	STW (P2+d),addr	4	14	CZN	word at P2+d:=word at addr. A!
$96	STW (P3+d),addr	4	14	CZN	word at P3+d:=word at addr (memory word -> local). A!
$98	LDW addr,#imm8	4	8	-	word at addr:=imm8 zero-extended (4 bytes).
$99	LDW addr,#imm16	5	9	-	word at addr:=imm16 (5 bytes).
$9A	ADDW dst,src	5	15	CZNV	word a:=a+b, 16-bit; C=carry out. A!; Z from the high byte only.
$9B	SUBW dst,src	5	15	CZNV	word a:=a-b, 16-bit; C=1 no borrow (a>=b unsigned). A!; Z high byte only.
$9C	CMPW dst,src	5	15	CZNV	flags from a-b (16-bit), memory unchanged: C=unsigned a>=b, BLT/BGE = signed. A!
$9E	INCW addr	3	9	CZN	word at addr += 1. A!; flags from the low byte.
$9F	DECW addr	3	9	CZN	word at addr -= 1. A!; flags from the low byte.
$A0	ADDW addr,#imm8	4	15	CZNV	word a:=a+imm8 (zero-ext), 16-bit; C=carry out; Z of the FULL word. A!
$A1	SUBW addr,#imm8	4	15	CZNV	word a:=a-imm8; C=1 no borrow; Z full word. A!
$A2	CMPW addr,#imm8	4	15	CZNV	flags from a-imm8 (16-bit), memory unchanged; Z full word (a==imm). A!
$A4	LEAW addr,(P1+d)	4	14	CZN	word at addr:=P1+d (the address of a frame local). A!
$A5	LEAW addr,(P2+d)	4	14	CZN	word at addr:=P2+d. A!
$A6	LEAW addr,(P3+d)	4	14	CZN	word at addr:=P3+d (address of a stack local). A!
$B1	ADDW addr,#imm16	5	15	CZNV	word a:=a+imm16; C=carry out; Z full word. A!
$B2	SUBW addr,#imm16	5	15	CZNV	word a:=a-imm16; C=1 no borrow; Z full word. A!
$B3	CMPW addr,#imm16	5	15	CZNV	flags from a-imm16, memory unchanged: C=a>=imm unsigned, Z=a==imm, BLT/BGE signed. A!
$B4	ANDW dst,src	5	15	ZN	word a:=a AND b; Z high byte only. A!
$B5	ORW dst,src	5	15	ZN	word a:=a OR b; Z high byte only. A!
$B6	XORW dst,src	5	15	ZN	word a:=a XOR b; Z high byte only. A!
$B7	ANDW addr,#imm8	4	15	ZN	word a:=a AND imm8 (high byte cleared); Z full word: `ANDW x,#1 / JZ` tests a bit. A!
$B8	ORW addr,#imm8	4	15	ZN	word a:=a OR imm8 (high byte kept); Z full word. A!
$B9	XORW addr,#imm8	4	15	ZN	word a:=a XOR imm8 (high byte kept); Z full word. A!
$BA	ANDW addr,#imm16	5	15	ZN	word a:=a AND imm16; Z full word. A!
$BB	ORW addr,#imm16	5	15	ZN	word a:=a OR imm16; Z full word. A!
$BC	XORW addr,#imm16	5	15	ZN	word a:=a XOR imm16 (#$FFFF = bitwise NOT); Z full word. A!
Control flow					
$40	JMP addr	3	5	-	P0(PC):=addr.
$41	JSR (P1)	1	9	-	Push return addr, P0:=P1.
$42	RTS	1	7	-	Pop return addr from P3 into P0.
$43	JSR addr	3	13	-	Push return addr, P0:=addr.
$48	BZ addr	3	5	-	Branch if Z=1. (JZ alias.)
$49	BNZ addr	3	5	-	Branch if Z=0. (JNZ alias.)
$4A	BCP addr	3	5	-	Branch if C=1 / A>=B unsigned. (JC alias.)
$4C	JNC addr	3	5	-	Branch if C=0 / A<B unsigned.
$A8	JMP rel8	2	14	-	P0:=P0+rel8 (2-byte jump; A/flags kept; assembler .relax / JMP.R).
$A9	BZ rel8	2	14	-	Branch rel8 if Z=1. (JZ.R alias.)
$AA	BNZ rel8	2	14	-	Branch rel8 if Z=0. (JNZ.R alias.)
$AB	BCP rel8	2	14	-	Branch rel8 if C=1. (JC.R alias.)
$AC	JNC rel8	2	14	-	Branch rel8 if C=0.
Signed branches (rev C; after CMP)					
$44	BLT addr	3	5	-	Branch if signed A<B (N^V=1). After CMP.
$45	BGE addr	3	5	-	Branch if signed A>=B (N^V=0). After CMP.
$46	BLE addr	3	5	-	Branch if signed A<=B ((N^V)|Z). After CMP.
$47	BGT addr	3	5	-	Branch if signed A>B. After CMP.
$AD	BLT rel8	2	14	-	Branch rel8 if signed A<B (N^V).
$AE	BGE rel8	2	14	-	Branch rel8 if signed A>=B.
$AF	BLE rel8	2	14	-	Branch rel8 if signed A<=B.
$B0	BGT rel8	2	14	-	Branch rel8 if signed A>B.
Pointer registers					
$31	LPL1 #imm	2	3	-	P1 low byte:=imm.
$32	LPL2 #imm	2	3	-	P2 low byte:=imm.
$33	LPL3 #imm	2	3	-	P3 low byte:=imm.
$35	LPH1 #imm	2	3	-	P1 high byte:=imm.
$36	LPH2 #imm	2	3	-	P2 high byte:=imm.
$37	LPH3 #imm	2	3	-	P3 high byte:=imm.
$54	INP1	1	2	-	P1:=P1+1.
$55	INP2	1	2	-	P2:=P2+1.
$56	INP3	1	2	-	P3:=P3+1.
$58	DEP1	1	2	-	P1:=P1-1.
$59	DEP2	1	2	-	P2:=P2-1.
$5A	DEP3	1	2	-	P3:=P3-1.
$5E	TAP1L	1	2	-	P1 low:=A.
$5F	TAP1H	1	2	-	P1 high:=A.
$60	TAP2L	1	2	-	P2 low:=A.
$61	TAP2H	1	2	-	P2 high:=A.
$62	TAP3L	1	2	-	P3 low:=A.
$63	TAP3H	1	2	-	P3 high:=A.
$68	TPA1L	1	2	ZN	A:=P1 low.
$69	TPA1H	1	2	ZN	A:=P1 high.
$6A	TPA2L	1	2	ZN	A:=P2 low.
$6B	TPA2H	1	2	ZN	A:=P2 high.
$6C	TPA3L	1	2	ZN	A:=P3 low.
$6D	TPA3H	1	2	ZN	A:=P3 high.