

Tens machine:

- Apply when pain is experienced, or you are about to undertake an activity that you know is likely to cause pain.
- Machine can be worn for up to 4 hours at a time and 3-4 times/day
- It does not matter which lead is black and which is red.
- It does not matter which side you insert the lead from the pads into the machine
- Turn the dial slowly until you hear a click, then “SLOWLY” turn the dial until you feel a tingle. You only need to feel the tingle, there is no benefit in turning the dial up to receive an increased sensation. If you turn the dial up too high, it will give a squeeze pain sensation
- Do not wear in bed in case you fall asleep with it on
- I would pull the lead out before you switch it off in case you turn the dial the wrong way
- Machine is pre-programmed – open the door and take a photograph of the settings in case they get moved in error
- Battery 9V – difficult to say how long they will last (depends on usage) – unfortunately re-chargeable batteries do not work well
- When not in use please apply pads back to plastic sheet – do not stick together or onto machine
 - Keep in packet at night – put in fridge as this helps keep stickiness
 - If less sticky – wet cotton tea towel (or something not fluffy) and dab pads with wet towel
- Tens sometimes has a build-up effect so please do not lose heart if not effective at the beginning
- Some people find tens only effective when being used but some people find effect last after tens removed
- This can be worn at school if necessary