



# DWF\_dp\_count\_ones functions

### Count-Ones

Version, STAR and Download Information: IP Directory

### **Description**

The DWF\_dp\_count\_ones functions count the number of bits with value 1 in argument vector a. Operation for unsigned and signed arguments is identical and the functions always return an unsigned value.

Table 1-1 Function Names

Function Name	Description	
DWF_dp_count_ones	VHDL unsigned count-ones	
DWF_dp_count_ones	VHDL signed (two's complement) count-ones	
DWF_dp_count_ones	VHDL std_logic_vector count-ones	
DWF_dp_count_ones	Verilog unsigned count-ones	
DWF_dp_count_ones	Verilog signed (two's complement) count-ones	

#### Table 1-2 Argument Description

Argument Name	Туре	Width / Values	Description
а	Vector	width	Input data
DWF_dp_count_ones	Vector	ceil(log <sub>2</sub> [width+1])	Return value

#### Table 1-3 Parameter Description (Verilog)

Parameter	Values	Description
width	≥ 1	Word length of input a

**Verilog Include File:** DW\_dp\_count\_ones\_function.inc

# **Functional Description**

For more information about the DesignWare datapath functions, refer to the topic titled DesignWare Datapath Functions Overview.

# **Related Topics**

- DesignWare Datapath Functions Overview
- DesignWare Building Block IP Documentation Overview

### **VHDL Example**

```
library IEEE, DWARE;
use IEEE.std_logic_1164.all;
use IEEE.numeric_std.all;
use DWARE.DW_dp_functions.all;
-- DWARE.DW_dp_functions_arith package if IEEE.std_logic_arith is used
entity DWF_dp_count_ones_test is
  port (a : in unsigned(7 downto 0);
        b : in unsigned(3 downto 0);
        z : out std_logic);
end DWF_dp_count_ones_test;

architecture rtl of DWF_dp_count_ones_test is
begin
  z <= '1' when (DWF_dp_count_ones (a) >= b) else '0';
end rtl;
```

# **Verilog Example**

```
module DWF_dp_count_ones_test (a, b, z);

input [7:0] a;
input [3:0] b;
output z;

// Passes the parameters to the function
parameter width = 8;

// add "$SYNOPSYS/dw/sim_ver" to the search path for simulation
'include "DW_dp_count_ones_function.inc"

assign z = (DWF_dp_count_ones (a) >= b) ? 1'b1 : 1'b0;
endmodule
```

### **Copyright Notice and Proprietary Information**

© 2018 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### **Disclaimer**

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### **Trademarks**

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at https://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

#### **Third-Party Links**

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc. 690 E. Middlefield Road Mountain View, CA 94043

www.synopsys.com