Nano sockets / USB power

AOG Nano carrier Rev A · Electrical connection reference · Same net names are electrically connected

J1 · Nano left socket

Pad 1 → unconnected: D13
Pad 2 → unconnected: 3V3
Pad 3 → unconnected: AREF
Pad 4 → A0
Pad 5 → unconnected: A1
Pad 6 → unconnected: A2
Pad 7 → unconnected: A3
Pad 8 → SDA_5V
Pad 9 → SCL_5V
Pad 10 → unconnected: A6
Pad 11 → unconnected: A7
Pad 12 → +5V
Pad 13 → unconnected: RESET_L
Pad 14 → GND
Pad 15 → unconnected: VIN

J2 · Nano right socket

Pad 1 → unconnected: D12
Pad 2 → unconnected: D11
Pad 3 → unconnected: D10
Pad 4 → unconnected: D9
Pad 5 → D8
Pad 6 → D7
Pad 7 → D6
Pad 8 → unconnected: D5
Pad 9 → D4
Pad 10 → unconnected: D3
Pad 11 → D2
Pad 12 → GND
Pad 13 → unconnected: RESET_R
Pad 14 → unconnected: RX
Pad 15 → unconnected: TX

Pin-number reference only; editable KiCad schematic accompanies this drawing. Nano USB end is socket pin 1.