

Build the two pivots

VBar case bodies and the retained SMUT pivots



STAGE 01 / 03

Install the inserts before the case bodies go on the radio. Left and right are viewed from the front.

1 INSERTS

Fit four M3 inserts in the case bodies, two M3 inserts in the pivot-stub blocks, and one M4 insert in the right plunger bore.

2 RIGHT DETENT

Key the replaceable ring onto the right stub, with its pockets toward the plunger. Mount the stub using an M4 x 20 screw, washer, and Nyloc nut.

3 LEFT PLAIN

Mount the left stub with the second M4 x 20 screw, washer, and Nyloc nut. Tighten both pivots fully; the sleeves must still rotate freely.

CHECKPOINT

Hardware tight, pivots free. The detent ring belongs on the RIGHT.

Clamp onto the handle

The VBar bodies and caps are distinct left/right parts



Actual VBar handle clamps on the radio. Confirm cap orientation from the L/R markings.

STAGE 02 / 03

The shallow L and R marks on each case and cap face inward toward the handle center.

1

TAPE FIRST

Place one thin strip of double-sided tape on top of the handle at each clamp position. Seat the left and right case bodies on the curved metal.

2

MATCH CAPS

Fit the L cap to the L body and the R cap to the R body. Install two M3 x 10 screws per cap, without washers.

3

SNUG ONLY

Tighten enough to hold position. Some wiggle and a visible cap-to-body gap are normal before the stand/header joins the two sides.

CHECKPOINT

Use M3 x 10 cap screws - the Spirit WAVE M3 x 12 length is different.

Attach and square the stand

40 mm keyed header centers and right-side detent



The actual V/BAR stand deployed on the completed VBar transmitter.

STAGE 03 / 03

Seat both pivot blocks fully in the V/BAR header, then bring the clamp assemblies square.

1

KEY THE HEADER

Use one M3 x 8 button-head screw and M3 washer at each stand mount. Start both screws slightly loose.

2

PUSH DOWN

As the stand screws are tightened, press the stand downward so the header clears the lower case corners. Tighten the four cap screws evenly, then finish the stand screws.

3

SET DETENTS

Thread the M4 ball plunger ball-first into the right insert. Adjust in small steps, then fold and deploy through the full range to check indexing and clearance.

CHECKPOINT

Cycle the stand fully. Stop and realign if the header catches either case corner.