

After starting the script, you will encounter several options:

• please specify kubot model

4. Initialization environment

./kubot2_ros/kubot_init_env.sh

• please specify kubot driver board type

- please specify your kubot lidar
- please specify the current machine
 - o Enter 0 for ROS master, Enter 1 and keyin ip for ROS slave

source ~/.bashrc

This script uses bash shell by default. If you use other shells, please modify all bashrc and bash words in the script.

5. Create ROS workspace

cd ~/kubot2_ros/ros_ws
catkin_make
source ~/.bashrc

Then you can enjoy KUBOT ROS!!

try roslaunch or keyin kubot_ TAB TAB, You can see many of the features command

roslaunch kubot_bringup bringup.launch
roslaunch kubot_navigation gmapping.launch

KUBOT2_ROS



Releases No releases published Create a new release Packages No packages published Publish your first package Contributors 2 kubot080301 Hong CJH-8 Languages C++ 51.5% C 21.7% Python 11.1% Roff 8.5% HTML 23% CMake 2.3% Other 2.6%