Nonlinear Dynamical Systems: Lecture 11

Madhu N. Belur & Harish K. Pillai Control & Computing group Department of Electrical Engineering Indian Institute of Technology Bombay

(IIT Bombay)

Lienard's equation

Let f and g be two continuously differentiable functions on R with f and g as even and odd function respectively.

Lienard's equation

Let f and g be two continuously differentiable functions on R with f and g as even and odd function respectively. Then the second order differential equation of the form

$$\ddot{x} + f(x)\dot{x} + g(x) = 0$$

is called the Lienard equation.

Lienard's equation

Let f and g be two continuously differentiable functions on R with f and g as even and odd function respectively. Then the second order differential equation of the form

$$\ddot{x} + f(x)\dot{x} + g(x) = 0$$

is called the Lienard equation.

A lienard system has a unique and stable limit cycle surrounding the origin if it satisfies the following properties:

A lienard system has a unique and stable limit cycle surrounding the origin if it satisfies the following properties:

1. g(x) > 0 for all x > 0.

A lienard system has a unique and stable limit cycle surrounding the origin if it satisfies the following properties:

- 1. g(x) > 0 for all x > 0.
- 2. F(x) < 0 for 0 < x < p and F(x) > 0 and monotonic for x > p.

A lienard system has a unique and stable limit cycle surrounding the origin if it satisfies the following properties:

- 1. g(x) > 0 for all x > 0.
- 2. F(x) < 0 for 0 < x < p and F(x) > 0 and monotonic for x > p.

Van der Pol Oscillator

Let $f(x) = \epsilon(1 - x^2)$ where $\epsilon > 0$ and g(x) = x then the system is called Van der Pol oscillator.

Van der Pol Oscillator

Let $f(x) = \epsilon(1 - x^2)$ where $\epsilon > 0$ and g(x) = x then the system is called Van der Pol oscillator. The differential equation becomes:

$$\ddot{\mathbf{x}} + \epsilon (1 - \mathbf{x}^2) \dot{\mathbf{x}} + \mathbf{x} = \mathbf{0}$$

Consider parallel RLC circuit where $L>0,\,C>0$ resistive element is an active circuit with v-i characteristic i=h(v).

- $h(\cdot)$ satisfies the following conditions:
 - 1. h(0) = 0.

Consider parallel RLC circuit where $L>0,\,C>0$ resistive element is an active circuit with v-i characteristic i=h(v).

- 1. h(0) = 0.
- 2. h'(0) < 0.

Consider parallel RLC circuit where L>0, C>0 resistive element is an active circuit with v-i characteristic i=h(v).

- 1. h(0) = 0.
- 2. h'(0) < 0.
- 3. $h(v) \rightarrow \infty$ as $v \rightarrow \infty$.

Consider parallel RLC circuit where L>0, C>0 resistive element is an active circuit with v-i characteristic i=h(v).

- 1. h(0) = 0.
- 2. h'(0) < 0.
- 3. $h(v) \to \infty$ as $v \to \infty$.
- 4. $h(v) \rightarrow -\infty$ as $v \rightarrow -\infty$.

Consider parallel RLC circuit where L>0, C>0 resistive element is an active circuit with v-i characteristic i=h(v).

- 1. h(0) = 0.
- 2. h'(0) < 0.
- 3. $h(v) \to \infty$ as $v \to \infty$.
- 4. $h(v) \rightarrow -\infty$ as $v \rightarrow -\infty$.

Applying KCL

$$i_C + i_L + i_R = 0.$$

Hence

$$C\frac{dv}{dt} + \frac{1}{L} \int v(t)dt + h(v) = 0$$

Differentiating once and dividing by CL

$$\frac{d^2v}{dt^2} + \frac{v}{LC} + \frac{h'(v)}{C}\frac{dv}{dt} = 0$$

The coefficient $\frac{h'(v)}{C}$ determines the damping of voltage.

The coefficient $\frac{h'(v)}{C}$ determines the damping of voltage. This nonlinear damping term determines energy exchange of the LC circuit with the resistive element. Let the active resistive element be negative resistance tunnel diode circuit as shown in the figure.

The coefficient $\frac{h'(v)}{C}$ determines the damping of voltage. This nonlinear damping term determines energy exchange of the LC circuit with the resistive element. Let the active resistive element be negative resistance tunnel diode circuit as shown in the figure. Then $h(v) = -v + \frac{1}{3}v^3$, $\frac{h'(v)}{C} = \frac{v^2-1}{C}$ Consider the following:

1. When $|\mathbf{v}| < 1$ damping is negative and energy is fed in.

The coefficient $\frac{h'(v)}{C}$ determines the damping of voltage. This nonlinear damping term determines energy exchange of the LC circuit with the resistive element. Let the active resistive element be negative resistance tunnel diode circuit as shown in the figure. Then $h(v) = -v + \frac{1}{3}v^3$, $\frac{h'(v)}{C} = \frac{v^2-1}{C}$ Consider the following:

- 1. When $|\mathbf{v}| < 1$ damping is negative and energy is fed in.
- 2. When $|\mathbf{v}| > 1$ damping is positive and energy is dissipated.

The coefficient $\frac{h'(v)}{C}$ determines the damping of voltage. This nonlinear damping term determines energy exchange of the LC circuit with the resistive element. Let the active resistive element be negative resistance tunnel diode circuit as shown in the figure. Then $h(v) = -v + \frac{1}{3}v^3$, $\frac{h'(v)}{C} = \frac{v^2-1}{C}$ Consider the following:

- 1. When $|\mathbf{v}| < 1$ damping is negative and energy is fed in.
- 2. When $|\mathbf{v}| > 1$ damping is positive and energy is dissipated.

Therefore the dynamics of the circuit are restricted in some area. For a given initial condition(eg.voltage of C), at some point of time in a cycle the energy that is fed in will be equal to the energy dissipated. At that time there will be stable oscillations or the trajectory will be a stable limit cycle.