- Recap: Lecture 8: 21st January 2014, 0830-0930 hrs.
 - First law for open systems
 - Conservation of mass
 - Flow work and the energy of a flowing fluid
 - Total energy of a flowing fluid
 - Energy analysis of steady flow systems
 - Steady flow energy equation
 - Nozzles/diffusers, compressors/turbines, throttling devices, mixing chambers

• Comparison of steady flow energy equation with Euler and Bernoulli equations

$$\dot{Q}_{\rm in} + \dot{W}_{\rm in} + \sum_{\rm in} \dot{m} \left(h + \frac{V^2}{2} + gz \right) = \dot{Q}_{\rm out} + \dot{W}_{\rm out} + \sum_{\rm out} \dot{m} \left(h + \frac{V^2}{2} + gz \right)$$
for each inlet

for each exit

The steady flow equation in differential form

$$\partial Q = dh + \overline{V}d\overline{V} + gdz + \partial W$$

Since h = u + pv and $\partial Q = du + pdv$ (for a quasi - static process involving only pdv work),

$$du + pdv = du + pdv + vdp + \overline{V}d\overline{V} + gdz + \partial W$$

For an inviscid frictionless flow, say, through a pipe

$$vdp + \overline{V}d\overline{V} + gdz = 0$$


This is the Euler equation.

If we integrate between two sections,


$$\frac{p}{\rho} + \frac{\overline{V}^2}{2} + gz = const.$$
 This is the Bernoulli equation.

• Unsteady flow processes

- important to keep track of the mass and energy contents of the control volume as well as the energy interactions across the boundary
- Charging, discharging of tanks from pipelines, inflating tyres or balloons, cooking in a pressure cooker



Charging if a rigid tank from a supply line is an unsteady process, due to changes within the control volume.




The shape and size of a control volume may change during an unsteady flow process.

The *mass balance* for any system undergoing any process can be expressed as

$$m_{\rm in} - m_{\rm out} = \Delta m_{\rm system}$$
 (kg)

where $\Delta m_{\rm system} = m_{\rm final} - m_{\rm initial}$ is the change in the mass of the system. For control volumes, it can also be expressed more explicitly as

$$m_i - m_e = (m_2 - m_1)_{CV}$$



- The bottle initially contains a mass m_1 at state P_1 , T_1 , v_1 , h_1 , and u_1 . As the valve is opened and gas flows into the bottle till mass m_2 at state P_2 , T_2 , v_2 , h_2 , and u_2 is attained.
- The state of the gas in the supply pipeline can be assumed to be constant P_p, T_p, v_p, h_p, u_p and V_p.

Energy of the gas before filling

$$E_1 = m_1 u_1 + (m_2 - m_1) \left(\frac{V_P^2}{2} + u_P \right)$$

Where, $(m_2 - m_1)$ is the mass of gas in the pipeline and the tube which would enter the bottle.

Energy of the gas after filling, $E_2 = m_2 u_2$

$$\Delta E = E_2 - E_1 = m_2 u_2 - \left[m_1 u_1 + (m_2 - m_1) \left(\frac{V_P^2}{2} + u_P \right) \right]$$

The KE and PE terms have been appropriately neglected.

Work done because of the collapse of the envelope of gas volume, $W = P_P(V_2 - V_1) = P_P[0 - (m_2 - m_1)v_P]$

$$=-(m_2-m_1)P_P v_P$$

Using the first for the process,
$$Q = \Delta E + W$$

$$Q = m_2 u_2 - m_1 u_1 - (m_2 - m_1) \left(\frac{V_P^2}{2} + u_P \right) - (m_2 - m_1) P_P v_P$$

$$= m_2 u_2 - m_1 u_1 - (m_2 - m_1) \left(\frac{V_P^2}{2} + h_P \right)$$

This gives the energy balance for this process.


This equation can also be derived using the control volume (Eulerian) approach.

Second law of thermodynamics


- Need for the second law of thermodynamics
 - Limitations of the first law of thermodynamics
 - Directionality of a process
 - Quality of energy
- Examples
 - A hot object does not get hotter in a cooler room.
 - Transferring heat to a resistor will not generate electricity.



A cup of hot coffee will not get hotter in a cooler room



Electricity cannot be generated by transferring heat to a wire



A paddle wheel cannot be rotated by transferring heat to it.

Second law of thermodynamics

- Processes proceed in a certain direction and not in the reverse direction.
- The first law places no restriction on the direction of a process.
- This inadequacy of the first law to identify whether a process can take place or not is remedied by the second law of thermodynamics.
- A process cannot occur unless it satisfies both the first and the second laws of thermodynamics.


Second law of thermodynamics

- The first law of thermodynamics was concerned only with the quantity of energy and its transformations.
- Second law reveals that energy has quantity as well as quality.
- Second law of thermodynamics determines theoretical limits for feasibility of a process.


Thermal energy reservoir

- A hypothetical body with a relatively large thermal energy (mass x specific heat).
- Supply or absorb infinite amounts of heat without any change in its temperature
- Eg. Oceans, lakes, atmosphere
- A reservoir that supplies energy in the form of heat: Source
- A reservoir that absorbs energy in the form of heat: Sink


- Work can be rather easily converted to heat.
- The reverse process is not easy and requires special devices: heat engines
- Receive heat from a high-temperature source (solar energy, oil furnace etc.).
- Convert part of this heat to work
- Reject the remaining waste heat to a low-temperature sink
- Operate on a cycle



Work can be easily converted to heat, but the reverse does not occur naturally.



Heat engines convert part of Q_{in} to $W_{net,out}$ and reject the balance heat to the sink.



• The net work output of the heat engine

$$W_{net,out} = W_{out} - W_{in}$$
 (kJ)

• The heat engine system may be considered as a closed system and hence $\Delta U=0$.

$$W_{net,out} = Q_{in} - Q_{out}$$
 (kJ)


Thermal efficiency

- Q_{out}: energy "wasted" during the process
- Only part of the heat input can be converted to useful work output.
- For heat engines, thermal efficiency is defined as

Thermal efficiency =
$$\frac{\text{Net work output}}{\text{Total heat input}}$$

$$\eta_{th} = \frac{W_{net,out}}{Q_{in}} = 1 - \frac{Q_{out}}{Q_{in}}$$
(since $W_{\text{net,out}} = Q_{in} - Q_{out}$)

Thermal efficiency



$$\eta_{th1} = \frac{25}{100} = 0.25$$

$$\eta_{th2} = \frac{35}{100} = 0.35$$

All heat engines do not perform the same way.

Thermal efficiency

- Even the most efficient heat engines reject a huge fraction of the input energy.
- Thermal efficiency of common heat engines
 - Automobile engines: 20-25%
 - Aero engines: 25-30%
 - Gas turbine power plants: 40%
 - Combined cycle power plants: 60%