

What it does: you type what's loaded in each hold position, the app compares it to the loadsheet target and tells you if it matches, then turns it into a CPM. Runs in any browser — phone, tablet or PC.

GOLDEN RULE — Green badge = the hold matches the loadsheet. Red = it doesn't. Make everything green, then generate the CPM.

1 Set up the flight

Top of screen, in order:

- **Theme** (Auto/Dark/Light) — top right.
- **Aircraft** — pick A390 or A333 first; it changes the hold layout.
- **Flight / Reg / Dest** — used on the CPM. Reg works with or without the dash.

REQUIRED Flight, Reg and Dest must be filled to generate a CPM — a missing one is highlighted red.

Sunclass Cargo Reconciler

AutoDarkLight

A330-900 · A390

A330-300 · A333

FLIGHT

REG

DEST

DK1192

e.g. OY-VKG

AGP

Reg missing → highlighted red on generate

2 Weight settings (set once)

Tap **Weight settings** under the flight details. Bag weight and container weights live here, remembered for next time. The two tick-boxes decide how Cargo/Mail on pallet (P) positions is counted:

- **Ticked** (normal) — the weight of the container is included in the weight you type in each compartment.
- **Unticked** — type the load only; the app adds the pallet weight on top.

UNSURE? Leave both ticked — that's the normal Sunclass way.

3 Fill each hold

Positions are laid out like the aircraft: **L** left, **P** middle, **R** right. Per hold:

1. Type the **target loadsheet weight**.
2. For each position, pick what it holds and type the number.
3. Watch the badge go **green**.

Button	You type
Bags	number of bags (× bag wt + container)
Cargo	weight in kg
Mail	weight in kg
Cat	nothing — auto-filled from target

HOLD 1

MATCH · 2500 kg

Sections 11–13 (A390)

TARGET LOADSHEET WEIGHT

2 500

11L Bags845

60

BagsCatCrgMail

11P Cargo1200

1200

CatCrgMail

11R Mail455

455

BagsCatCrgMail

P tile (middle) has no Bags button; badge green when totals hit target

4 Generate the CPM

Tap **Generate CPM** in the bottom bar. Fill the few things the app doesn't know:

- **Date** (defaults to today), **ULD suffix** (DK), optional **SI**.
- **ULD number** per position. L/R positions are always AKE; **P** positions are PMC or PLA. There's a Toggle all to set every P position at once.

ALWAYS INCLUDED Catering positions (code K) and the Hold 5 bulk compartment (line **-5/...**, no ULD) are always in the message. Tick **INCLUDE EMPTY POSITIONS** to also list unloaded positions as **/N**.

Generate CPM

DATE

11 Jul 2026

ULD SUFFIX

DK

11P

Cargo · 1200 kg

PMC

PLA

30142

11L

Bags · 845 kg

AKE

12345

L/R fixed to AKE · P toggles PMC/PLA

5 Copy, share, edit

The result gives a readable table and the raw message. You can:

- **Edit the raw text** directly.
- **Copy** or **Share...** (phone share menu).
- ← **Edit source data** to change inputs; **Regenerate** to rebuild from data (drops manual text edits).

NOT A TRANSMITTABLE MESSAGE It's a working CPM to check/paste — send it through your normal channel, not as-is.

New flight

Clear all wipes everything (holds, flight, CPM). Weight settings and theme are kept. Closing the CPM window with × keeps your entries.

DK1192/11JUL.OY-VKR
-11P/PMC30142DK/AGP/1200/C
-11L/AKE12345DK/AGP/845/B
-11R/AKE30876DK/AGP/455/M
-5/AGP/260/B
-13L/N
SI TWO WHEELCHAIRS HOLD 1

← Edit source

Regenerate

Copy raw text

Share...

Finished CPM — editable, copy or share