

METU

FACULTY OF ARCHITECTURE

LASER CUTTER MANUAL

Our Faculty has a Universal PLS6.150D and a VLS 6.60 laser cutter. Before using the laser cutter, all users should read the guide carefully and make reservation for the laser cutter at least two days in advance. During the peak times of the semester, the reservations should be made at least a week in advance.


1. File setups

The laser cutter machine cuts and etches only vector data. You can use different programs such as AUTOCAD, CORELDRAW, ILLUSTRATOR, and RHINO ETC. as long as your files are saved in DXF format.

In order to prepare your drawings for laser cutter, you will need to organize your drawings.

1.1. The drawings should be adjusted to the size of the laser cutter's bed (810x 450 mm).

A very simple way to adjust your drawing is to draw a box as a template on model space and to place the drawing into this box (template) to ensure that your drawing is not truncated.



In order to minimize the wasted material, all the pieces should be arranged in the most efficient configuration. Additionally, by labeling each piece, you can make easier to construct your model. Please use only **iso.txt** as text style for your part labels.

- Please don't forget to remove duplicate lines. Commands for removing duplicate lines are **overkill** (Autocad) and **Seldup** (Rhino).