

## Modify package dependency

1. Right click on selected package and select "Update Package Properties"




2. Add xxx\_dev dependency to "Build Details" for build time.




10.194.49.234:3000/s/HknNBh12v 1/3

3. Add xxx dependency to "Binary Packages" for runtime.




4. Save and then "Update Package" and "Repack Package", you may get error message during repack, it doesn't matter.



10.194.49.234:3000/s/HknNBh12v 2/3

5. Open PRJ file, select the package parameters, save it and build.



10.194.49.234:3000/s/HknNBh12v 3/3