


1) Simulation before Running code



2) Source Code

The screenshot shows the Source Code window in Proteus 8 Professional. The source code for the assembly file 'main.asm' is displayed. The code is as follows:

```

1  ORG 0000H
2  UP: SETB P2.0
3  ACALL DELAY
4  CLR P2.0
5  ACALL DELAY
6  SJMP UP
7  DELAY: MOV R4,#35
8  H1:MOV R3,#255
9  H2:DJNZ R3,H2
10 DJNZ R4,H1
11 RET
12 END
  
```

3) Simulation After Running code

