
Components - EMEA

Engineering Solutions Center - Arrow EMEA



Quick Start Guide

©2017 by ARROW All rights reserved. No part of this manual shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, desktop publishing, recording, or otherwise, without written permission from the publisher. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this document, the publisher and author assume no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. All terms mentioned in this manual that are known to be trademarks or service marks are listed below. In addition, terms suspected of being trademarks or service marks have been appropriately capitalized. ARROW cannot attest to the accuracy of this information. Use of a term in this document should not be regarded as affecting the validity of any trademark or service mark.

Revision History

Revision, Date	Editor	Subject (major changes)
Revision 1.0,	ESC	First revision
23.11.2018		

Table of Contents

Revision History	3
Table of Contents	4
How to flash an Android Image on the DragonBoard	5
Hardware Requirements	
Creating Modified Debian Image	
Compiling and Testing tom2-tss and tom2-tss-engine	

How to flash an Android Image on the DragonBoard

Hardware Requirements

The following equipment is needed to flash and run your DragonBoard™ 410c with Tresor:

- DragonBoard™ 410c + Power Supply
- Tresor Mezzanine Card
- Linux Host PC (Tested with Ubuntu)
- Micro-USB Cable (x2 flashing and debugging)




Figure 1 - Setup for flashing the DragonBoard™410c

Creating Modified Debian Image

Download latest prebuilt Debian developer (not installer) SD-card image from:

http://releases.linaro.org/96boards/dragonboard410c/linaro/debian/latest/

Write it to uSD card!

See the how-to under the following link:

https://www.96boards.org/documentation/consumer/dragonboard/dragonboard410c/installation/linux-sd.md.html

Check the "release notes" for preparing to rebuild the kernel on the linux host machine:

http://releases.linaro.org/96boards/dragonboard410c/linaro/debian/latest/

Start rebuilding the kernel with the following steps:

```
$ git clone -n http://git.linaro.org/landing-teams/working/qualcomm/kernel.git
$ cd kernel
$ git checkout -b kernel-18.01 debian-qcom-dragonboard410c-18.01
```

Modify the kernel by applying changes in kernel_diff.txt (available at arrow.com tresor product page):

```
$ git apply .../kernel_diff.txt
```

Continue and finish building the kernel following the remaining steps in the "release notes" up to building boot-db410c.img

HINT: on Ubuntu 16.04 one may use 'abootimg' instead of 'mkbootimg'.

Update the boot partition of the previously prepared uSD card (see "Release Notes")

HINT: for updating without fastboot: one can simply write the Linux boot image to "boot" partition of the uSD card. To get partition names execute:

```
$ sudo parted /dev/sdX print -s
```

Do not forget to copy kernel modules to the 'rootfs' partition on the uSD card!

Attach Tresor v1.1 board to Dragonboard410c, set jumpers to enable TPM2.0 module, connect the USB-serial converter to PC, on the PC open a terminal emulator program and configure the serial port to 115200,N81 - see *Figure2*.



Figure 2 - Jumper set up

Insert uSD card, reboot and verify the presence of the TPM2 SPI driver with following commands:

Compiling and Testing tpm2-tss and tpm2-tss-engine

Configure WiFi as described here (don't download new SD-card image, use the running Linux):

https://discuss.96boards.org/t/headless-mode-with-wifi-vnc-server-and-xfce-desktop/5279

VNC is not needed, only WiFi.

Install the following packages:

```
$ su - linaro
$ sudo apt-get update
$ sudo apt-get -y install aptitude autoconf autoconf-archive automake \
   autotools-dev build-essential cmocka-doc libcurl4-gnutls-dev libgcrypt20-dev \
   libglib2.0 libglib2.0-dev libcmocka-dev libssl-dev libtool m4 man-db pandoc \
   pkg-config ruby-ronn uthash-dev zliblg-dev
```

Let's get tpm2-tss and build it:

```
$ git clone https://github.com/tpm2-software/tpm2-tss
$ cd tpm2-tss/
$ ./bootstrap
$ ./configure --with-udevrulesdir=/etc/udev/rules.d --with-udevrulesprefix
$ make -j4
$ sudo make install
```

Same for tpm2-tools:

```
$ cd
$ git clone https://github.com/tpm2-software/tpm2-tools
$ cd tpm2-tools/
$ ./bootstrap
$ ./configure
$ make -j4
$ sudo make install
```

Same for tpm2-tss-engine:

```
$ cd
$ git clone https://github.com/tpm2-software/tpm2-tss-engine
$ cd tpm2-tss-engine/
$ ./bootstrap
$ ./configure
$ make -j4
$ sudo make install
$ sudo cp /usr/local/lib/openssl/engines/libtpm2tss.* /usr/lib/aarch64-linux-gnu/engines-1.1/
$ sudo ldconfig
$ cd
$ sudo make install
```

Now we can verify tpm2-tools:

```
$ sudo tpm2_getcap -c ecc-curves
TPM2_ECC_NIST_P256: 0x3
TPM2_ECC_BN_P256: 0x10
```

Verify the OpenSSL TPM2 engine:

HINT: this last line of the code is a random HEX number generated by the Optiga TPM.

It is now possible to try all the openssl features mentioned here:

https://github.com/tpm2-software/tpm2-tss-engine/blob/master/README.md

Some caveats about the above page:

- always replace "-engine tpm2tss" with "-engine libtpm2tss" everywhere
- execute all the tools as root (eg. with 'sudo')
- sample calls sometimes have wrong arguments. Read the man pages of the given call for the correct arguments. For example:

```
'tpm2tss-genkey -a rsa -s 2048 mykey' Instead of 'tpm2tss-genkey -a rsa -k 2048 mykey'
```

Here are some instructions about using commands of the tpm2-tools package to sign and verify documents:

https://dquerriblog.wordpress.com/2016/03/03/tpm2-0-and-openssl-on-linux-2/