+ Direction DMA_Stream_TypeDef + PeriphInc CR + MemInc + PeriphDataAlignment **NDTR PAR** + MemDataAlignment + M0AR + Mode + Priority M1AR **FCR** + FIFOMode + FIFOThreshold + MemBurst + PeriphBurst +Init +Instance DMA_HandleTypeDef + Lock + State UART_InitTypeDef + Parent + BaudRate + XferCpltCallback + WordLength + XferHalfCpltCallback + StopBits + XferM1CpltCallback + XferM1HalfCpltCallback + XferErrorCallback + HwFlowCtl + XferAbortCallback + OverSampling + ErrorCode + StreamBaseAddress + StreamIndex +hdmarx +Init +hdmatx UART_HandleTypeDef pTxBuffPtr **TxXferSize** TxXferCount pRxBuffPtr RxXferSize RxXferCount ReceptionType RxEventType

USART_TypeDef

SR

DR

BRR

CR1

CR2

CR3

GTPR

+ Parity

+ Mode

+Instance

Lock gState **RxState** ErrorCode DMA_InitTypeDef

+ Channel