

---Firmware Upgrade---

1. Download the firmware update kit from the website using a PC or Mac.
(<https://www.nuxefx.com/atlantic.html>)
2. Connect your NDR-5 to your Mac or PC using a quality micro USB sync/data cable.
3. 3A. Run "NUX Device Firmware Updater (DFU)".
3B. Hold down the "DELAY" and "Reverb" footswitch together and plug in your power supply (9V/DC, Negative Center). Release both foot-switches when you see "Device connected.".
4. 4A. Select the new firmware file(bin file) that was downloaded along with the NUX Device Firmware Updater(DFU).
4B. Click "Start Update" button.
5. Wait until the update is completed. During the upgrade process, both LED indicators will keep flashing, and once the progress is done, both LED indicators stays on.
6. Finish updating.
6A. Close "NUX Device Firmware Updater (DFU)".
6B. Unplug the power supply and micro-USB cable from the pedal.
6C. Try out the new features and tones.

You can also ref to this tutorial made by our friends Ryan Lutton: https://youtu.be/pxpXoFZ_yUw