

Référence / Reference : Révision / Revision : A

Titre /Title: SDK 6.2 release delivery

Programme / Subject:

	Nom Name	Fonction Function
Etabli par : Vritten by:	J.R. Poligny	project manager
/érifié ou Approuvé par : Checked or approved by:	C.Barthelemy	Export Product leader
Autorisé par : Authorized by:	C.Barthelemy	Export Product leader

Révision	Date de validité / d'application	Nb de pages	Nb de pages annexes	Objet et description de la modification
Issue	Validity/application date	Nb of pages	Nb of appendices	Object and description of modification
A	March 2009			Release SDK 6.2



## 1 INTRODUCTION

# THIS DOCUMENT DESCRIBES THE CONTENT OF THE SDK 6.2 DELIVERY.

!!!!!! Be Careful, the format of the SDK release has changed : !!!!!

There are now two new digits for describing integration or dedicated deliveries

## **2 TELIUM SYSTEM**

The System delivery is the pack 7.67

## 2.1 EVOLUTIONS

!!! Be careful, for migration purpose, it s now possible to manage up to 7 levels of directory in Flash

if you update your Telium configuration with SDK 6.0, IT S NOT POSSIBLE to switch back to former SDKs !!!

FT 4242 - ICT220 : Improve the printer contrast .

- Color display management
- GSM Hilo driver improvement

#### 2.2 BUG FIX ON

FT 4179 ICT220 : Correction on SDRAM management.

FT 4250 EFT30 / 30+ : Freeze after connection of P30 on EFT30

This problem occur only on product manufactured during 2003 and beginning of

2004.

FT 4278 EFT30 : error on product name. EFT30 is defined as "EFT SMART". After

correction, the product name is "EFT30F".

# 3 <u>TELIUM MANAGER</u>

#### 3.1 **EVOLUTIONS**

New functions have been added to customize:

SMO/ Rév.: A Page: 1



- Idle state
- Card Insertion
- Messages
- Black and white / colour compatibility

## 4 SCHEMES

#### TELIUM1:

A new directory "DEBUGSigned" has been added:

The goal is to provide a way to debug application using schemes even if the signature card is not provided.

#### principle:

the terminal to be used for development is initialised with a special security profile (T10) and in mockup mode

schemes are provided "T10 signed" with the SDK ("debug" directory)

SST is used to generate the mockup application

#### SST installation:

Proceed to SST installation

copy the files provided (Wordwide debug) under SST installation folder:

SST database files (SST30-WGM.MDW and SST30-WGM.MDB)

SST30.INI file

Check that SST30.INI file is like this:

[Options]

Mockup=Yes

copy "T10 signed" schemes under "C:\Program Files\TELIUM Tools\SST30 V04.02\Signed Schemes"

#### SST in graphic mode:

select schemes to be embedded in application and use "sign an application"

=> application is generated with a fake signature/certificate

#### SST in command mode:

specify "00000000" as password in .bat file

=> application is generated with a fake signature/certificate

SMO/ Rév.: A Page: 2



## Application:

VAR\_NUMBER\_SIGN for DEBUG is 0xFA (for SEC\_CreateSecretArea function)

## TELIUM2:

A new directory "DEBUGSigned" has been added:

The goal is to provide a way to debug application using schemes even if the signature card is not provided.

## principle:

the terminal to be used for development is initialised with a special security profile (T10) and in mockup mode

schemes are provided "T10 signed" with the SDK ("debug" directory)

SAT is used to generate the mockup application

## 5 TOOLS

BuildMSG is updated and manage more than 1000 messages.

SMO/ Rév.: A Page: 3