BOSS & FRIENDS
CONSTRUCTION LTD.

FREE CHECKLIST

BEFORE THE POUR: 30 CHECKS

Once the concrete is in, every mistake is permanent, and fixing it means a saw, a jackhammer or an engineer's letter. Run this list the day before and again the morning of the pour. Print it and hand it around.

BUILDERS & GCS · CREWS & FOREMEN · EVERY TRADE IN THE SLAB · HOMEOWNERS

1 PAPERWORK & INSPECTIONS

NO SIGN-OFF, NO POUR

- [ ] **Permit on site, latest approved drawings in hand.** Check the revision date. Everyone works off the same set. BUILDER
- [ ] **Required inspections booked and passed.** The municipal footing/foundation inspection, plus the engineer's field review where the design calls for one. BUILDER
- [ ] **Layout verified.** Setbacks, gridlines and elevations checked against the site plan. A form survey is done if your municipality requires one. BUILDER
- [ ] **Mix ordered to spec.** Strength (MPa), exposure class, air content, slump and aggregate size, all matching the drawings. BUILDER CREW
- [ ] **Volume, start time and truck spacing confirmed with the plant.** Order a small overage so you're not short on the last wall. CREW

2 FORMS

BLOWOUTS START WHERE NOBODY CHECKED

- [ ] **Dimensions and diagonals checked.** Forms square, plumb and in line with the drawings.
- [ ] **Bracing, stakes and walers solid.** Walk the full run and push on it.
- [ ] **Top of pour marked** with grade nails, a chalk line or tape, so the finisher knows where to stop.
- [ ] **Ties at the form system's spacing;** release agent on the panels.
- [ ] **Bulkheads and keyways set** wherever the pour stops (planned cold joints).
- [ ] **Bottom clean.** No mud, standing water, debris, frost or ice. Footings bear on undisturbed or properly compacted soil.

3 REBAR

THE PART NOBODY SEES AGAIN

- [ ] **Size, spacing and laps match the drawings;** laps tied.
- [ ] **Cover is right.** Chairs and dobies hold steel off the ground and off the forms (typically 75 mm where concrete is cast against earth; confirm on your drawings).
- [ ] **Dowels and verticals tied in place.** No "wet-sticking" unless the engineer allows it.
- [ ] **Steel is clean:** no mud, oil or loose, flaky rust.
- [ ] **Corner bars and extra bars at openings** placed as detailed.

4 EVERY TRADE: WHAT GETS BURIED

GET EACH TRADE'S OK BEFORE THE TRUCK

- [ ] **Plumbing:** sleeves for sewer, water and drain lines through footings and walls. Under-slab rough-in tested and inspected. PLUMBER
- [ ] **Electrical:** grounding electrode (concrete-encased / "Ufer") in place if the electrician specified it; conduit sleeves set. ELECTRICIAN
- [ ] **Framing:** anchor bolts and hold-downs at the right spacing, embedment and location. Use templates; don't eyeball them. FRAMER
- [ ] **Mechanical & gas:** sleeves for lines and venting; radon / soil-gas rough-in where required. HVAC GAS
- [ ] **Drainage:** perimeter drain tile plan agreed, and every under-slab or through-wall sleeve in. BUILDER
- [ ] **Openings:** beam pockets, window bucks and blockouts in the right place and braced. FRAMER CREW
- [ ] **Photograph everything**: rebar, sleeves and embeds, before the pour. When it's buried, the photos are your only record. EVERYONE

5 SITE, WEATHER & CREW

POUR DAY RUNS ON PREP

- [ ] **Truck and pump access:** path clear, ground firm enough, washout spot set. Never wash out into a storm drain.
- [ ] **Overhead power lines located.** The pump boom stays outside WorkSafeBC limits of approach.
- [ ] **Forecast checked.** Have a cold-weather plan (blankets, heat) if it's heading under 5 °C, and a curing plan for hot or windy days.
- [ ] **Crew briefed:** who's on the hose, vibrator, screed and finish. Agree hand signals with the pump operator.
- [ ] **Tools ready:** a vibrator plus a backup, screeds, floats, water, and lights if it runs late.
- [ ] **PPE for wet concrete:** waterproof gloves, boots with pants over the top, eye protection. Wet concrete burns skin.

6 AFTER THE POUR

BONUS

- [ ] **Cure and protect.** Keep it moist or covered and protected from freezing. Strip forms and backfill only when the engineer or spec says so.

✓ POUR-DAY SIGN-OFF

EVERY TRADE INITIALS BEFORE THE FIRST TRUCK

TRADE / ITEM	CHECKED BY	INITIALS	TIME
Forms & rebar			
Inspection / engineer			
Plumbing			
Electrical			
Framing (bolts / hold-downs)			
Mechanical / gas			

Homeowner? You don't need to check the rebar yourself, but you can ask your contractor two questions: **"Did the inspection pass?"** and **"Can I see the photos before the pour?"** A good crew says yes right away.