Harnesses

14A488 .....G2,E1,C8

C Numbers

C210(M) In-line (14A488 to 14398) B1
C212(M) In-line (14A488 to 14401)) B3
C264(F) In-line (14A488 to 2B325).....C1
C265(M) In-line (14A488 to 14334) B2
C270a Central Junction Box (CJB) B1
C310b Restraints Control Module (RCM).....F3
C311(M) In-line (14A488 to 14B079) D3
C313(F) In-line (14A488 to 14407) G3
C314(F) In-line (14A488 to 14C719) A5
C315(M) In-line (14A488 to 14C719).....B4
C316(F) In-line (14A488 to 14C719).....B4
C327(M) In-line (14A488 to 14C719) F1
C328(F) In-line (14A488 to 14C719) F3
C339(F) In-line (14A488 to 14C719) F2
C340(F) In-line (14A488 to 14C719) F2
C421(M) In-line (14A488 to 13B431) G7
C431(M) In-line (14A488 to 14A583) A6
C432(M) In-line (14A488 to 14A583) A6
C456 Liftgate door lock switch.....F8
C2015 Park brake switch E1
C2065a Illumination dimmer G4
C2065b Illumination dimmer G5
C2231a Variable Assist Power Steering (VAPS) module.....B2
C2231b Variable Assist Power Steering (VAPS) module.....A2
C3008d Central Security Module (CSM).....C8
C3008e Central Security Module (CSM).....B8
C3008f Central Security Module (CSM).....B8
C3047(F) In-line (14A488 to 14335) A5
C3050(M) In-line (14A488 to 2C011) F4
C3055 Side air curtain module, left.....B5
C3056 Side air curtain module, right.....B7
C3165 Power point, right rear C8
C3209 Side impact sensor, driver 1.....F3

C Numbers

C3210 Side impact sensor, driver 2.....G4
C3211 Side impact sensor passenger 1.....E5
C3212 Side impact sensor, passenger 2.....B7
C4082 Antenna gain module B8
C4207a Telematics Control Unit (TCU) module G6
C4207b Telematics Control Unit (TCU) module G6
C4207c Telematics antenna F5
C4207d Telematics antenna.....G5
C4207e Telematics antenna.....A7
C4207f Telematics antenna.....B7

Grounds

G205 .....E1
G207 .....C3
G400 .....A5
G401 .....F7
G402 .....D8