Excursion


Heated seat module, passenger side front
119–2
1
C329
57
16 BK
Seat heater switch, passenger side
119–2
2
4
C321
without power seats
with power seats
57
18 BK
57
18 BK
S355
with power seats
Seat adjust switch, passenger side front
120–2
8
C330
57
14 BK
S335
57
16 BK
57
18 BK
57
14 BK
4
C340
See page 10–9
Seat heater switch, driver side
119–1
4
2
C320
57
18 BK
57
18 BK
Safety belt buckle switch (10B924)
66–2
3
C323
57
20 BK
Heated seat module, driver side front
119–1
1
C359
57
16 BK
Driver seat module (14C718)
123–2
2
C341b
57
14 BK
S332
57
14 BK
4
C327
57
14 BK
S306
57
14 BK