C316

14A005



F02042

14B719



F02107

C318a

14A005

A219
Cellular phone
handset



F10075

Pin	Circuit	Circuit Function
1	9-MC10 (BN/YE)	Sensor signal return (reference/ ground)
2	2-MC10 (GY/BK)	Audio signal negative
3	1-MC10 (WH/BK)	Audio signal positive
4	31-MC10 (BK/RD)	Ground
5	8-MC10 (WH/BK)	Sensor signal
6	5-MC10 (BU/YE)	Data link, bus negative
7	4-MC10 (GY/BK)	Data link, bus positive
8	7-MC10 (YE/BK)	Voltage D.C. supplied at all times (sensor)
9	91-MC10 (BN/YE)	Ground
10	10-MC10 (GY/BK)	Signal 2 (Y–direction, reverse, downward)

C318b

14A005

A219
Cellular phone
handset



F01059