Master window adjust switch (14529) – Expedition (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Power and Ground Checks Before Any Other Tests	8 and 7, C504b	Window lockout Off	Closed circuit
	5, C504b and 1, 2, 3, 4, 5, 6, 7, 8 C504a	Rest	
	8, C504b and 1, 2, 3, 4, 5, 6, 7, 8 C504a	Rest	Open circuit
Driver front window circuit	8, C504b and 5, C504a	Up	Closed circuit
	6, C504a and 5, C504b		
	8, C504b and 6, C504a	Down	
	5, C504a, and 5, C504b		
		Up	800Ω – 1000Ω
one–touch down	5, C504b and 8, C504b	Rest	800Ω – 1000Ω
Passenger front window circuit	8, C504b and 7, C504a	Up	Closed circuit
	8, C504a, and 5, C504b		
	8, C504b and 8, C504a	Down	
	7, C504a, and 5, C504b		
Left rear window circuit	8, C504b and 2, C504a	Up	Closed circuit
	1, C504a and 5, C504b		
	8, C504b and 1, C504a	Down	
	2, C504a and 5, C504b		
Right rear window circuit	8, C504b and 3, C504a	Up	Closed circuit
	4, C504a and 5, C405b		
	8, C504b and 4, C504a	Down	
	3, C504a and 5, C504b		
Illumination	Connect pin 8, C504b to 12V DC power and pin 5, C504b to ground.	Visually inspect switch to verify illumination.	