

1 2 3 4 5 6 7 8
A B C D E F
C1066
Idle air control valve (IAC) (9F715)
C1072
EGR vacuum regulator solenoid (9J459)
C174
Ignition transformer capacitor 1 (18801)
C1061
Engine Coolant Temperature (ECT) sender
12B637
C110
C186
Injector 6 (9F593)
C189
Throttle Position Sensor (TPS) (9B989)
C1064
Engine Coolant Temperature (ECT) sensor (12A648)
C1068
Differential pressure feedback EGR (DPFE) sensor (9J460)
C185
Injector 5 (9F593)
C184
Injector 4 (9F593)
C101
Crankshaft position sensor (6C315)
C180
Camshaft position sensor (6B288)
engine, front