
Component number
Name of component
Details about component or operation
Component connector number
N278
Ignition switch
(11572)
0) Off
1) Acc
2) Run
3) Start
3 2 1 0
3 C300
Switches that move together
2 1 2 1
Dashed line shows a mechanical connection between switches
Normally open contact
When coil is energized, switch is activated
2 1
One pole, two position switch
2 1
Fuse condition
Component number
Name of component
Base part number
Hot at all times
P91
Central Junction Box (CJB)
(14A068)
F23
3A
720 20 RD/YE
5 C220
A30
Instrument cluster
6) Illumination
6
4 C220
Details about component or operation
Splice
See page 13–1
Reference to page where circuit is shown complete
Component connector number
S64
19 20 LB/RD
17 C175
A147
Powertrain Control Module (PCM)
(12A650)
33 19 C175
57 20 BK 57 20 BK
Wire insulation is one color
Dashed line indicates terminals for the same connector
4 2 C201
S101
See page 10–1
G1002
G1001
Ground numbered for reference to component location chart
Other circuits which are also grounded at G100, but are not shown, can be found using the reference