
Hot at all times
F25
20A
Hot in start or run
F30
7.5A
Hot at all times
F34
7.5A
P91
Central Junction Box (CJB) (14A068)
K106
Anti–theft flasher relay
A38
Central Timer Module (CTM)
E171
PATS indicator
D20
Data Link Connector (DLC) (14489)
A68
Remote control unit
radio signal
A77
Anti–theft/central locking module
H5
Anti–theft horn
N98
Tailgate/decklid anti–theft inhibit switch
Controls remote entry system. Anti–theft/central locking module processes radio frequency signals from the remote transmitter to unlock all doors, lock all doors or sound a panic alarm.
M68
Door lock motor, passenger side
N103
Left front door courtesy lamp switch
N100
Right front door courtesy lamp switch
N22
Liftgate/decklid switch
M67
Door lock motor, driver side
A11
Radio (18806)
Directs ground signal to anti–theft/central locking module for door ajar status.