Harnesses

14401 .....F4,A2

C Numbers

C205a Main light switch.....C8
C205b Main light switch.....B8
C205c Main light switch.....E8
C209 Footwell lamp, left front.....F5
C212(F) In-line (14401 to 14A488).....E2
C213(M) In-line (14401 to 19B113).....E2
C220a Instrument cluster, inboard.....B7
C220b Instrument cluster, outboard.....B8
C228a Electronic Automatic Temperatare Control (EATC) module.....B6
C228b Electronic Automatic Temperature Control (EATC) module.....A6
C233 In-vehicle temperature sensor.....A7
C238(F) In-line (14401 to 19C603).....F3
C239 Trailer electronic brake control module.....F4
C240a Audio unit, CDX6.....A4
C240b Audio unit, CDX6.....A5
C240c Audio unit, CDX6.....A4
C251 Data Link Connector (DLC), OBD II.....G5
C254 Glove box lamp.....A2
C256 Passenger air bag module.....A3
C260(F) In-line (14401 to 19B113).....F1
C263(F) In-line (14401 to 14398).....F8
C266 Footwell lamp, right front.....F2
C270d Central Junction Box (CJB).....F7
C270e Central Junction Box (CJB).....G6
C270f Central Junction Box (CJB).....G7
C270g Central Junction Box (CJB).....G7
C270h Central Junction Box (CJB).....F6
C282 Inertia Fuel Shutoff (IFS) switch.....F2
C286 Sunload sensor.....A3
C290a Audio unit, DM100.....A5
C290b Audio unit, DM100.....A4

C Numbers

C2016 Clock.....B5
C2093 Remote solenoid assembly.....F3
C2094 Memory set switch.....A8
C2235 Adjustable pedal switch.....A6
C2253b Navigation head unit.....A3
C2253c Navigation head unit.....A5
C2253d Navigation head unit.....A4
C4033 Fuel pump driver module.....A1

Grounds

G202 .....F1