
A188
Module, power sliding door, LH side
A212
Rear Electronic Module (REM)
59–7
130–4
Radio
132–5
Rear Seat Entertainment (RSE)
with rear radio control unit
827 18 TN/WH
800 18 GY/LB
801 18 TN/YE
1251 18 YE/RD
1252 18 GY/RD
1227 18 WH
1387 18 VT
1388 18 GY
C3072a
C3072b
C3070c
C399
N431
Sliding door contact switch, left
825 18 TN/LG
803 18 BN/PK
C702
Y17
Speaker, left rear (18808)
S700
C711
N333
Detent switch, LH
C709
N600
Latch reverse actuator, left power sliding door
1385 18 LG
1386 18 OG
C706
C708
M212
Door lock actuator assembly, left sliding door