C414

14A005

E9
Lamp assembly, left
rear (13405)



F03099

Pin	Circuit	Circuit Function
1	29S-LF23 (OG)	Voltage supplied at all times (overload protected), switch
2	31S-LF11 (BK/WH)	Ground, switch
3	31S-LG14 (BK/OG)	Ground, switch

C417

14A005

E10
Lamp assembly,
right rear (13404)



F03099

Pin	Circuit	Circuit Function
1	29S-LF24 (OG/BK)	Voltage supplied at all times (overload protected), switch
2	31S-LF20 (BK/OG)	Ground, switch
3	31S-LG21 (BK/GN)	Ground, switch