
See page
123–2
A
6
C334
SB02
2 WH/RD
1
C303
RD
S341
RD
RD
11
1
C360
N422
Power seat switch, right
0) Rest
1) Backrest forward
2) Backrest rearward
5) Seat forward
6) Seat rearward
1 0 2
1 0 2
5 0 6
5 0 6
4
5
12
6
2
7
C360
GY
YE
BK
OG
GN
BK
S319
BK
4
1
5
6
C358
2
C303
See page
10–14
G300
M215
Power seat motor assembly, right
1) Seat forward/rearward
3) Backrest forward/rearward
M
M
3
1