-1



Instrument Panel and Console
501-12-00

Entertainment System – General Information
415-00-00

Instrument Cluster
413-01-00

Instrument Cluster and Panel Illumination
413-00-00

Climate Control System – General Information
412-00-00

Anti–Theft – Active
419-01A-00

Anti–Theft – Passive
419-01B-00

Warning Devices
413-09-00

Automatic Transaxle/ Transmission External Controls
307-05-00

Roof Opening Panel
501-17-00

Rear View Mirrors
501-09-00

Interior Lighting
417-02-00

Seating
501-10-00

Fuel Charging and Controls – ZETEC
303-04A-00

Fuel Charging and Controls – Duratec
303-04B-00

Starting System
303-06-00

Engine Ignition – ZETEC
303-07A-00

Engine Ignition – Duratec
303-07B-00

Electronic Engine Controls
303-14-00

Vehicle Speed Control
310-03-00

Wipers and Washers
501-16-00

Module Communications Network
418-00-00

Exterior Lighting – Licence plate lamps
417-01-00

Exterior Lighting – Stoplamps
417-01-00

Exterior Lighting – Reversing lamps
417-01-00

Exterior Lighting – Trailer tow
417-01-00

Handles, Locks, Latches and Entry Systems
501-14-00

Glass, Frames and Mechanisms
501-11-00

Occupant Restraints – Active
501-20A-00

Occupant Restraints – Passive
501-20B-00

Horn
413-06-00

Anti–Lock Control
206-09-00

Automatic Transmission/Transaxle
307-01-00

Multifunction Electronic Control Modules
419-10-00

Brake System – General Information
206-00-00

Four–Wheel Drive System
308-07A-00

Charging System – General Information
414-00-00

Engine Cooling
303-03-00

Exterior Lighting – Headlamps
417-01-00

Exterior Lighting – Turn Signal Lamps
417-01-00

Exterior Lighting – Position and Parking Lamps
417-01-00

Exterior Lighting – Fog lamps
417-01-00

Daytime Running Lamps
417-04-00