C912

14334

N411
Roof opening panel
switch (15B691)



F07044

Pin	Circuit	Circuit function
1	57 (BK)	Illumination, Ground
2	–	not used
3	1174 (WH/RD)	Power sliding roof Down, Open
4	1173 (BN/OG)	switch, Signal return
5	19 (LB/RD)	Illumination
6	1175 (TN/RD)	Power sliding roof, Up, Close
7	–	not used

C919

14A504



F12044

14A504



F12043