

Front door, with power equipment

14630	E 2	C622	F 3
14631	E 2	M79	Power window motor, passenger side front	C 1
C504	D 5	M80	Power window motor, driver side front	C 1
C505	C 5	M241	Door lock actuator, left front	B 2
C522	F 3	M242	Door lock actuator, right front	B 2
C523	E 4	M259	Exterior rear view mirror, left	F 3
C524	C 1	M260	Exterior rear view mirror, right	F 3
C525	B 2	N84	Door ajar switch, left front	A 3
C526	A 3	N85	Door ajar switch, right front	A 3
C527	E 5	N105	Window adjust switch, passenger side	D 5
C602	A 3	N204	Door lock switch, driver side	C 5
C603	B 2	N205	Door lock switch, passenger side	C 5
C604	D 5	N409	Exterior rear view mirror switch	E 5
C605	C 5	N447	Master window adjust switch	D 5
C608	C 1	Y18	Speaker, right front	E 4
C612	E 4	Y28	Speaker, left front	E 4