

On steering column

14401	Main wiring harness	E	1
A102	Passive anti–theft transceiver module	B	3
B36	Steering position sensor	B	1
C390		B	3
C441		B	5
C456		E	4
C459		D	5
C818		B	1
C896		B	3
N104	Wiper/washer switch	B	5
N278	Ignition switch	E	4
N282	Multifunction switch	D	5
P13	Clock spring	B	3