

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C190	59-9
C191	59-9
C192	59-10
C239	60-5
C240	60-5
C241	60-6
C340	59-12
C341	59-12
C343	59-13
C344	59-14
C346	59-10

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.