Components **Cell 151**

Location	Page/coordinates
Interior lamp relay	
in Central Junction Box (CJB)	9 – E 1
Knock sensor (12A699)	
engine, rear, RH side	2 – E 4
Main light switch (11654)	
behind dash panel, LH side.	9 – B 2
Mass Air Flow (MAF) sensor (12B579)	
in air cleaner assembly	6 – E 2
Multifunction switch (13K359)	
Steering Column, LH side	8 – B 3
Oil pressure switch (9278)	
engine, LH side	2 – F 3
Output Shaft Speed (OSS) sensor (7M101)	
transmission, top	1 – F 5
Parking brake switch (15A851)	
Steering Column, LH side	8 – D 1
PCM Module power diode	
in Battery Junction Box (BJB)	5 – A 1
PCM power relay	
in Battery Junction Box (BJB)	5 – B 1
Powertrain Control Module (PCM) (12A650)	
Steering Column, LH side	7 – F 2
Rear axle speed sensor (4B409)	
vehicle rear-end-J3231. . . !!!No Data Found!!! . .	10 – B 3
Speed control servo (9C735)	
engine bulkhead, RH side	7 – C 5
Starter motor (11002)	
engine, RH side, rear, bottom	4 – E 2
Starter relay (11450)	
behind radiator grille, RH side	3 – A 5
Steering wheel/speed control switch (9F924)	
in steering wheel	
Throttle Position Sensor (TPS) (9B989)	
engine, top.	1 – B 2
Trailer exterior lamp relay	
Auxiliary relay box 1	6 – E 1
Trailer tow relay, reversing lamp	
Auxiliary relay box 1	6 – E 1
Transmission control switch	
Steering Column	7 – B 2
Turbine shaft speed sensor (7M101)	
transmission, top	1 – C 5
Turn relay, left	
in Central Junction Box (CJB)	9 – E 2
Turn relay, right	
in Central Junction Box (CJB)	9 – E 2
Warning buzzer/chime module	
behind dash panel	8 – F 4
Wheel speed sensor, left front (2C205)	
behind wheel, Front, LH side	7 – F 3
Wheel speed sensor, left rear	
vehicle rear end, LH side	
Wheel speed sensor, right front (2C204)	
behind wheel, front, RH side	3 – E 3
Wheel speed sensor, right rear	
vehicle rear end, RH side	
Wiper Control Module (WCM)	
behind dash panel	8 – F 3
Wiper relay, high speed	
Supplied by body builder	
Wiper relay, low speed	
Supplied by body builder	