Harnesses

14683 .....C8
14A488 .....G5

C Numbers

C701 Window adjust switch, left rear.....B8
C702 Speaker, left rear C8
C703 Power window motor, left rear G3
C704 Door lock actuator, left rear B2
C715 Door ajar switch, left rear.....E2
C810(F) In-line (14683 to 14A488).....E8
C810(M) In-line (14A488 to 14683) G6