87-3 AUTOLAMPS/DELAYED EXIT



C260

AUTOLAMP SENSOR

PIN	CIRCUIT	CIRCUIT FUNCTION
1	1205 (BK)	Ground
2	–	NOT USED
3	–	NOT USED
4	1416 (YE/WH)	Autolamp Sense Return
5	–	NOT USED
6	640 (RD/YE)	Power Feed (Hot in Start or Run)

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C190	59-9
C192	59-10
C239	60-5
C240	60-5
C241	60-6