C112

12B637



!!! No Data Found !!!

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1027 (PK/LB)	Coil On Plug (COP) 2 (12029), control

C113

12B637



Coil On Plug (COP)
3 (12029)

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1026 (PK/WH)	Coil On Plug (COP) 3 (12029), control

C114

12B637



Coil On Plug (COP)
4 (12029)

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1141 (YE/BK)	Coil On Plug (COP) 4 (12029), control

C115

12B637



Coil On Plug (COP)
5 (12029)

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1028 (WH/PK)	Coil On Plug (COP) 5 (12029), control

C116

12B637



Coil On Plug (COP)
6 (12029)

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1025 (OG/YE)	Coil On Plug (COP) 6 (12029), control

C117

12B637



Coil On Plug (COP)
7 (12029)

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1030 (DG/VT)	Coil On Plug (COP) 7 (12029), control