Power window switch, driver (Regular cab, Super cab)

Terminals

C535



F08341

Schematic



Master window adjust switch (14529)

- **0) Rest**
- **1) Driver**
- **2) Passenger**
- **5) Up**
- **6) Down**
- **7) One–touch down**