125-1 AUTOMATIC DAY/NIGHT MIRROR

For diagnostic information, refer to Section 501-09 of the Workshop Manual.

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C168	29-6



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.