* SUPERCREWZER



C329 / *C260
PRIMARY SHIFT SELECTOR

PIN	CIRCUIT	CIRCUIT FUNCTION
A	170 (RD/LB)	To Electronic Control Unit
B	171 (BK/WH)	To Electronic Control Unit
C	172 (LB/RD)	To Electronic Control Unit
D	173 (DG/PK)	To Electronic Control Unit
E	174 (GY/BK)	To Electronic Control Unit
	–	NOT USED
L	176 (PK/LG)	To Electronic Control Unit/Diagnostic Connector
M	175 (BK/YE)	To Electronic Control Unit
N	124 (BN)	To Electronic Control Unit
P	143 (LB/YE)	To Electronic Control Unit
R	136 (DB/YE)	To Electronic Control Unit
S	180 (RD/YE)	To Electronic Control Unit
	–	NOT USED
T	186 (BK/LB)	Ground
U	187 (DB/OG)	Illumination
V	188 (WH/BK)	Ground

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C156	23-3
C201	13-34
C202	59-6
C203	59-8
C207	13-36
C213	60-7
C214	60-8