C1065

12B637

T1
Ignition coil



F04215

Pin	Circuit	Circuit Function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	96 (TN/OG)	Ignition coil
3	97 (TN/LG)	Ignition coil
4	95 (TN/WH)	Ignition coil

C1066

12B637

Y133
Idle air control valve
(IAC)



F02091

Pin	Circuit	Circuit Function
1	361 (RD)	Voltage supplied in Start and Run (overload protected)
2	264 (WH/LB)	Idle air control valve (IAC), control

C1068 (GY)

12B637

B257
Differential Pressure
Feedback EGR
(DPFE) sensor

2.5L, 3.0L



F03071

4.0L



F03201

Pin	Circuit	Circuit Function
1	351 (BN/WH)	Reference, voltage
2	359 (GY/RD)	signal, return
3	352 (BN/LG)	Differential Pressure Feedback EGR (DPFE) sensor, input

C1072

12B637

Y205
EGR vacuum regulator solenoid



F02101

Pin	Circuit	Circuit Function
1	34 (LB/OG)	Voltage supplied in Start and Run (overload protected)
2	360 (BN/PK)	EGR Vacuum Regulator (EVR), control